



**WARNING**



**INSTALLATION SHOULD ONLY BE  
PERFORMED BY QUALIFIED  
INSTALLATION PERSONNEL AND MUST  
CONFORM TO ALL NATIONAL AND  
LOCAL CODES**



## Hi5 Controller Function Manual

**BD525 PROFINET-IO**





---

The information included in this manual is the property of HHI.  
This manual may not be copied, in part or in full, without prior written authorization from HHI.  
It may not be provided to any third party, nor used for any other purposes.

HHI reserves the right to modify the content of this manual without prior notification.

Printed in Korea – Jan. 2014 1<sup>st</sup> Edition  
Copyright © 2014 by Hyundai Heavy Industries Co., Ltd





# Contents

<b>1. Overview</b>	<b>1-1</b>
1.1. Advance knowledge	1-2
1.2. Overview of PROFINET IO	1-2
1.3. Appearance of the BD525 board	1-3
1.3.1. PROFINET IO-Controller	1-4
1.3.2. PROFINET IO-Device	1-4
1.4. BD525 PROFINET IO specification	1-5
<b>2. EtherNet Connection</b>	<b>2-1</b>
2.1. Communication connector	2-2
2.2. Communication cable	2-3
<b>3. PROFINET IO-Device Setting &amp; Diagnosis</b>	<b>3-1</b>
3.1. PROFINET IO-Device setting	3-2
3.2. STEP7 PROFINET IO-Device setting	3-4
3.3. PROFINET IO-Device diagnosis	3-10
<b>4. PROFINET IO-Controller Setting &amp; Diagnosis</b>	<b>4-1</b>
4.1. SYCON.net	4-2
4.2. PROFINET IO network configuration	4-3
4.3. PROFINET IO-Controller setting	4-10
4.4. PROFINET IO-Controller diagnosis	4-12
<b>5. I/O Mapping</b>	<b>5-1</b>
5.1. PROFINET IO Input & Output Signal Mapping	5-2
5.2. Assignment of output signals related to communication errors	5-3

## Contents

---

### Figure Contents

Figure 1.1 PROFINET IO communication connect.....	1-2
Figure 1.2 BD525 PROFINET IO communication board .....	1-3
Figure 2.1 RJ45 socket pin map .....	2-2
Figure 2.2 Connecting Direct cable.....	2-3
Figure 2.3 Connecting Crossover cable.....	2-3
Figure 2.4 Connecting Direct cable.....	2-4
Figure 2.5 Connecting Direct cable.....	2-4
Figure 3.1 Real time Ethernet setting and diagnosis menus .....	3-2
Figure 3.2 PROFINET IO-Device setting screen .....	3-3
Figure 3.3 Function On/Off setting screen .....	3-3
Figure 3.4 PROFINET IO-Device diagnosis screen .....	3-10
Figure 4.1 USB connection between SYCON.net and BD525 .....	4-2
Figure 4.2 Real time Ethernet setting and diagnosis menus .....	4-10
Figure 4.3 PROFINET IO-Controller setting screen .....	4-11
Figure 4.4 PROFINET IO-Controller diagnosis screen .....	4-12
Figure 5.1 Communication error output signal assignment .....	5-3



### Table Contents

Table 5-1 PROFINET IO input and output data .....	5-2
---	-----



**HYUNDAI**  
HEAVY INDUSTRIES CO., LTD.

1

Overview



# 1. Overview

## 1.1. Advance knowledge

In order to understand this manual clearly, the following information should be possessed.

- Method for using the Hi5 robot controller
- Basic knowledge about the PROFINET

## 1.2. Overview of PROFINET IO

PROFINET IO is an Ethernet-based open-type industrial communication protocol that has progressively evolved from PROFIBUS-DP and industrial Ethernet. It conforms to the provider/consumer model for data exchange and can be subdivided into three classes of product groups, namely, IO-Controller, IO-Device, and IO-Supervisor.




Figure 1.1 PROFINET IO communication connect

- (1) IO-Controller  
Equivalent to the existing PROFIBUS-DP Class1 Master and is operated by an automated program along with PLC. IO-Controller provides output data to the IO-Devices that are assigned to it and consumes data inputted by the IO-Devices.
- (2) IO-Device  
Equivalent to the existing PROFIBUS-DP Slave and is connected through PROFINET IO to the IO-Controller along with PLC. IO-Devices provide input data to IO-Controller and consume data outputted by IO-Controller.
- (3) IO-Supervisor  
Equivalent to the existing PROFIBUS-DP Class 2 Master, and is composed of programming device, PC, HMI, etc., for the purpose of network configuration and diagnosis.



### 1.3. Appearance of the BD525 board




Figure 1.2 BD525 PROFINET IO communication board

BD525 board is composed of PROFINET IO-Controller and ROFINET IO-Device and can be supplied as either IO-Controller or IO-Device; assembled during production as needed.

### **1.3.1. PROFINET IO-Controller**

- It has two RJ45 connectors to connect with PROFINET IO. As they are connected internally with an embedded switch, it is possible to use either of them to connection communication cables.
- For network configuration of the PROFINET IO-Controller of BD525, you should use separate software called SYCON.net. To connect with the configuration device in which SYCON.net is installed, a USB port is provided.

### **1.3.2. PROFINET IO-Device**

- To connect with PROFINET IO, it has two RJ45 connectors that are connected internally with an embedded switch. To connect with the communication cable, any of them can be used.
- PROFINET IO-Device of BD525 does not require separate configuration software. The USB socket of the IO-Device is used for manufacturer maintenance.



### 1.4. BD525 PROFINET IO specification

<b>Size of input and output data</b>	Max.120Bytes
<b>Input and output data mapping</b>	PROFINET IO-Controller = FB1 object PROFINET IO-Device = FB3 object
<b>Min. cycle time</b>	1ms
<b>Communication speed</b>	10/100 Mbit/s (Auto-Negotiation supported)
<b>Data transport layer</b>	Ethernet II, IEEE 802.3
<b>Integrated switch</b>	Supported
<b>DCP function</b>	Supported







**HYUNDAI**  
HEAVY INDUSTRIES CO., LTD.

2

Ethernet  
Connection



## 2. Ethernet Connection

BD525 PROFINET IO

### 2.1. Communication connector

BD525 provides two RJ45 sockets each for both IO-Controller and IO-Device to connect with PROFINET IO.

Two Ethernet ports are connected internally through a switch.


	Pin No.	Signal	Meaning
	1	TD+	Sent data +
	2	TD-	Received data -
	3	RD+	Received data +
	4	No use	
	5	No use	
	6	RD-	Received data -
	7	No use	
	8	No use	

Figure 2.1 RJ45 socket pin map

### 2.2. Communication cable

Cables of CAT5 or higher grade and RJ45 connectors need to be used for connecting the BD525 PROFINET IO board, through a network, with a hub, switches and other PROFINET IO devices. As the BD525 board supports the auto crossover function, direct or crossover connection can be made as necessary.

- When to be connected with a hub or a switch




Figure 2.2 Connecting Direct cable




Figure 2.3 Connecting Crossover cable

- When to be directly connected with an PROFINET IO device



Figure 2.4 Connecting Direct cable




Figure 2.5 Connecting Direct cable

In order to increase noise immunity, **it is recommended to use STP (Shielded Twisted Pair) cables.** For details of cable wiring, please refer to the PNO installation guide.





**HYUNDAI**  
HEAVY INDUSTRIES CO., LTD.

**3**

**PROFINET  
IO-Device  
Setting & Diagnosis**



### 3. PROFINET IO-Device Setting & Diagnosis

BD525 PROFINET IO

#### 3.1. PROFINET IO-Device setting

It is required to set Device name and the size of input and output data to use an PROFINET IO-Device as shown in the following procedure.

- (1) Select 『[F2]: System』 → 『2: Control parameter』 → 『2: Input/Output signal setting』 → 『14: BD525 real-time Ethernet setting and diagnosis』 .




Figure 3.1 Real time Ethernet setting and diagnosis menus

### 3. PROFINET IO-Device Setting & Diagnosis

- (2) As the PROFINET IO-Device corresponds to Channel 3, Use the 『[F3]: Previous』 or 『[F4]: Next』 key to shift to Channel 3 and then check whether the Device Type shows “PROFINET IO Device”.




Figure 3.2 PROFINET IO-Device setting screen

- (3) Input device name. The node is identified with the device name by PROFINET IO-Controller. Communication becomes available if the name is the same as the one used in the configuration software of PROFINET IO-Controller in STEP 7.
- (4) Set size of I/O based on PROFINET IO-Controller. The input pertains to FB3.Y. The output pertains to FB3.X of the robot controller. The default size of the input and output data is 120 bytes.
- (5) Configure handling option of input data in case of communication errors. If it is set as Clear, all FB3.X's will be cleared to 0 in case of a communication error. If it is set as Hold, the last valid value will be maintained in case of a communication error.
- (6) In order to use the PROFINET IO-Device, shift it to the “On” position and then click the “Apply” or “Complete” button.





Figure 3.3 Function On/Off setting screen

### 3.2. STEP7 PROFINET IO-Device setting


The following is an example of the configuration method of connecting PROFINET IO-Device of the Hi5 robot controller using STEP 7.

- (1) Run 『HW Config』 of STEP 7.




### 3. PROFINET IO-Device Setting & Diagnosis

- (2) In the 『Option』 menu list, click 『Install GSD File』 .




- (3) In the 『Install GSD Files』 dialog box, select 『from the directory』 and click the 『Browse』 button.
- (4) Select the PROFINET IO-Device GSDML file of Hi5 controller and click the 『install』 button. When the warning message appears, confirm and click the 『Yes』 button.




- (5) When the GSDML file of Hi5 controller has been installed, click 『OK』 , and click the 『Close』 button of 『Install GSD Files』 .

- (6) In 『PROFINET IO\Additional Field Devices\General\Robot Controller』 of the 『Catalog』 window under 『HW Config』, check for the Hi5 BD525 item.




- (7) Drag and drop Hi5 BD525 to the 『PROFINET IO』 of 『HW Config』.



- (8) In the BD525 device of the 『Catalog』 window, expand the 『Input Modules』 folder and the 『Output Modules』 folder.

### 3. PROFINET IO-Device Setting & Diagnosis

- (9) Click the Hi5 BD525 icon of the PROFINET IO bus. Drag 120 bytes input to slot 1 and drag 120 bytes output to slot 2 to match the I/O size configured at the Hi5 controller.



## Reference)

The default size of the input data of the Hi5 controller is 120 bytes. If you have modified configuration of the I/O size of the Hi5 controller, you have to the drag input data size, which matches the modified I/O size, to the pertaining slot.

When input data size is 1~9, 10 bytes, 20 bytes, 30 bytes, 40 bytes, 50 bytes, 60 bytes, 70 bytes, 80 bytes, 90 bytes, 100 bytes, 110 bytes, or 120 bytes, the input module will use slot 1. Otherwise, two slots (slot 1 and slot 2) will be used as follows, and the output module will use slots from slot 3.

- slot 1 = input data size / 10
- slot 2 = input data size % 10

When output data size is 1~9, 10 bytes, 20 bytes, 30 bytes, 40 bytes, 50 bytes, 60 bytes, 70 bytes, 80 bytes, 90 bytes, 100 bytes, 110 bytes, or 120 bytes, the output module will use only one slot. Otherwise, two slots will be used as follows. (n: starting number of output module slot).

- slot n = output data size / 10
- slot n+1 = output data size % 10

For example, if the input data size is 119 bytes, and the output data size is 32 bytes, the module will be configured as follows:


- slot 1 = 11 Bytes input
- slot 2 = 9 Bytes input
- slot 3 = 3 Bytes output
- slot 4 = 2 Bytes output

**HYUNDAI**  
HEAVY INDUSTRIES CO.,LTD.




### 3. PROFINET IO-Device Setting & Diagnosis

- (10) Double click the Hi5 BD525 icon of the PROFINET IO bus to open the 『Object Property』 box. In the 『Device name』 column, input the device name that was configured at the Hi5 controller.



- (11) Check the 『Assign IP address via IO controller』 item in the 『Object Property』 box of Hi5 BD525 and click the 『OK』 button.



- (12) Click 『Save and Compile』 in the 『Station』 menu.

- (13) Click 『Download』 in the 『PLC』 menu.

### 3.3. PROFINET IO-Device diagnosis

It is possible to use a teach pendant to check the diagnosis information such as communication state, setting state and error information.









- (1) Select 『F2]: System』 → 『2: Control parameter』 → 『2: Input/Output signal setting』 → 『14: Real time Ethernet setting and diagnosis』 .
- (2) As the PROFINET IO-Device corresponds to the channel 3, use the 『F3]: Previous』 or 『F4]: Next』 key to shift to the channel 3.

<b>Device state</b> <input checked="" type="radio"/> Communication <input checked="" type="radio"/> Run <input type="radio"/> Ready <input type="radio"/> Error	<b>Configuration state</b> <input type="radio"/> Setting locked <input type="radio"/> New setting wait <input type="radio"/> Reset required <input checked="" type="radio"/> Bus ON	<b>Network state</b> 정상 <b>Error code</b> 0x0 <b>Error count</b> 1 <b>Slave state</b> - <b>Slave error count</b> -
---	---	--

Figure 3.4 PROFINET IO-Device diagnosis screen









- (3) Can check the information such as system state, setting state and error codes.

■ System state

LED	Meaning	Color	State	Remarks
Communication	communication state	 (Green)	Communication in progress	
		 (White)	Communication stopped	
Run	setting state	 (Green)	Setting normal	
		 (White)	Setting abnormal	
Ready	system state	 (Yellow)	System normal	
		 (White)	System abnormal	
Error	error state	 (Red)	Error generated	Refer to error codes
		 (White)	No error	

### 3. PROFINET IO-Device Setting & Diagnosis

#### ■ Setting state

LED	Meaning	Color	State	Remarks
Setting lock	Whether setting is locked	 (Green)	Locked	
		 (White)	Unlocked	
New setting ready	Whether new setting is ready	 (Green)	Setting ready	
		 (White)	Setting not ready	
Reset needed	Whether system reset is needed	 (Green)	Reset is needed	
		 (White)	Reset not needed	
Bus on	Whether bus communication is in progress	 (Green)	Communication started	
		 (White)	Communication stopped	

#### ■ Network state

State	Meaning
Normal	Ethernet communication is in progress normally.
Stopped	Ethernet communication is stopped.
Idle	No communication.
Offline	The network is offline.

## ■ Error codes

Error codes	Meaning
0x00000000	No error
0xC0000145	Ethernet cable connection is poor
0xC0000144	IP address is overlapped
0xC0000142	Connection timeout
0xC0000141	Disconnected
0xC0000140	Other types of network problems
Others	Inquiry to the manufacturers

## ■ Error frequency: Accumulated number of communication errors



**HYUNDAI**  
HEAVY INDUSTRIES CO., LTD.

**4**

**PROFINET  
IO-Controller  
Setting & Diagnosis**



## 4. PROFINET IO – Controller Setting & Diagnosis

BD525 PROFINET IO

### 4.1. SYCON.net

The BD525 PROFINET IO-Device can be set and diagnosed using a teach pendant. However, for setting the PROFINET IO-Controller, a separate network configuration tool, SYCON.net, which is software for Windows, is needed. Support is provided for the USB connection between SYCON.net and the BD525 board.





Figure 4.1 USB connection between SYCON.net and BD525

### 4.2. PROFINET IO network configuration


The following procedure should be observed to configure the network of the BD525 PROFINET IO-Controller. Refer to the SYCON.net manual for more details.

- (1) Insert the PROFINET IO-Controller NETX 100 RE/PNM  
Drag the “NETX 100 RE/PNM” from the device catalog of SYCON.net and drop it to the [network view] line.




- (2) Register the PROFINET IO-Device GSDML file to SYCON.net  
Execute **[Network > Import Device Description]** to register the GSDML file of the PROFINET IO-Device that needs to be connected to the PROFINET IO-Controller, and then register it to the [device catalog] of SYCON.net
- (3) Reload the device catalog  
After executing **[Network > Device Catalog]**, click the [Reload Catalog] button to reload the [device catalog] of SYCON.net to allow the newly registered adapter to be displayed.

- (4) Insert the PROFINET IO-Device  
 Drag the PROFINET IO-Device that needs to be connected to BD525 from the device catalog of SYCON.net, and drop and connect it to the bus of the [network view].



- (5) PROFINET IO-Device Module Setting  
 Double click the icon of the PROFINET IO-Device module that is to be connected with BD525 and set module configuration. Click the "Modules" item under "Configuration" located to the left of netDevice, and click the "Add Module" button to add the module.







## 4. PROFINET IO - Controller Setting & Diagnosis

- (6) Set the PROFINET IO-Controller (NETX 100 RE/PNM)  
Double-click the NETX 100 RE/PNM icon to set the following items.


- ① Select **[Settings > Driver]** and [netX Driver] and click the “Apply” button.  
(Check the checkbox for [netX Driver] and then click the “Apply” button.)



- ② Select **[Settings > Device Assignment]** and then select the scanner and then click the “Apply” button. If the PROFINET IO-Controller does not show up, change the [Device selection] to the “All” state and then click the “Scan” button.




- ③ Select **Configuration > Network Settings** and then set the network information such as the IP address of the PROFINET IO-Controller and then click the “Apply” button.




## 4. PROFINET IO - Controller Setting & Diagnosis

- ④ Select **[Configuration > Device Table]**, set [Name of station], and click the "Apply" button.




- ⑤ Select **[Configuration > IP Address Table]**, set IP, and click the "Apply" button.



## 4. PROFINET IO - Controller Setting & Diagnosis

- ⑥ Select **[Configuration > Station Timing]**, set IO scan time, and click the "Apply" button.



- (7) PROFINET IO-Controller (NETX 100 RE/PNM) setting  
Click the **[Device > Download]** menu, and download the set information.

### 4.3. PROFINET IO-Controller setting

The following procedure should be observed for the configuration of PROFINET IO-Controller at the robot controller:

- (1) Select 『[F2]: System』 → 『2: Control parameter』 → 『2: Input/Output signal setting』 → 『14: BD525 real-time Ethernet setting and diagnosis』




Figure 4.2 Real time Ethernet setting and diagnosis menus

## 4. PROFINET IO - Controller Setting & Diagnosis

- (2) As the PROFINET IO-Controller corresponds to the channel 1, use the 『[F3]: Previous』 or 『[F4]: Next』 key to shift to the channel 1, and then check whether Device Type shows “PROFINET IO-Controller”.




Figure 4.3 PROFINET IO-Controller setting screen

- (3) Can select an option regarding how to handle the input when a communication error occurs. When the option is set as “Clear”, the input data (FB1.X) will be cleared to be “0”. On the contrary, if it is set as “Hold”, the last valid value that is to be generated when the error occurs will be maintained.
- (4) In order to use the PROFINET IO-Controller, shift it to the “On” position and then click the “Apply” or “Complete” button.

## 4.4. PROFINET IO-Controller diagnosis

It is possible to use a teach pendant to check the diagnosis information such as communication state, setting state and error information of PROFINET IO-Controller.

- (1) Select 『[F2]: System』 → 『2: Control parameter』 → 『2: Input/Output signal setting』 → 『14: Real time Ethernet setting and diagnosis』
- (2) As the PROFINET IO-Controller corresponds to the channel 1. Use the 『[F3]: Previous』 or 『[F4]: Next』 key to shift to the channel 1.











Figure 4.4 PROFINET IO-Controller diagnosis screen











## 4. PROFINET IO - Controller Setting & Diagnosis

(3) Can check various information such as system state, setting state and error codes.

■ System state

LED	Meaning	Color	State	Remarks
Communication	communication state	 (Green)	Communication in progress	
		 (White)	Communication stopped	
Run	setting state	 (Green)	Setting normal	
		 (White)	Setting abnormal	
Ready	system state	 (Yellow)	System normal	
		 (White)	System abnormal	
Error	error state	 (Red)	Error generated	Refer to error codes
		 (White)	No error	

■ Setting state

LED	Meaning	Color	State	Remarks
Setting lock	Whether setting is locked	 (Green)	Locked	
		 (White)	Unlocked	
New setting ready	Whether new setting is ready	 (Green)	Setting ready	
		 (White)	Setting not ready	
Reset needed	Whether system reset is needed	 (Green)	Reset needed	
		 (White)	Reset not needed	
Bus on	Whether bus communication is in progress	 (Green)	Communication started	
		 (White)	Communication stopped	

■ Network state

State	Meaning
Normal	Ethernet communication is in progress normally.
Stopped	Ethernet communication is stopped.
Idle	No communication.
Offline	The network is offline.

## 4. PROFINET IO - Controller Setting & Diagnosis

### ■ Error codes

Error codes	Meaning
0x00000000	No error
0xC0000145	Ethernet cable connection is poor
0xC0000144	IP address is overlapped
0xC0000142	Connection timeout
0xC0000141	Disconnected
0xC0000140	Other types of network problems
Others	Inquiry to the manufacturers

### ■ Error frequency: Accumulated number of communication errors

### ■ Slave state

Slave state	Meaning
Normal	No error
Error	communication error occurs

### ■ Number of slaves that have errors: Shows the number of the PROFINET IO-Device that has communication errors.





**HYUNDAI**  
HEAVY INDUSTRIES CO., LTD.

**5**

**I/O Mapping**



## 5. I/O Mapping

BD525 PROFINET IO

### 5.1. PROFINET IO Input & Output Signal Mapping

The input and output data of the BD525 PROFINET IO-Controller and IO-Device will be mapped individually not only to the robot language, but also to the FB1 and FB3 objects of the embedded PLC. There are 960 X inputs and 960 Y outputs. They are accessible through 5 different types as shown in Table 5-1.

Table 5-1 PROFINET IO input and output data

Classification		Command grammar	Size	Description	Remarks
BD525 PROFINET IO-Controller	Controller output	FB1.Y1~960	960	Bit signal output	
		FB1.YB1~120	120	Byte signal output	
		FB1.YW1~60	60	Word signal output	
		FB1.YL1~30	30	Double word signal output	
		FB1.YF1~30	30	Float signal output	
	Controller input	FB1.X1~960	960	Bit signal input	
		FB1.XB1~120	120	Byte signal input	
		FB1.XW1~60	60	Word signal input	
		FB1.XL1~30	30	Double word signal input	
		FB1.XF1~30	30	Float signal input	
BD525 PROFINET IO-Device	Controller output	FB3.Y1~960	960	Bit signal output	
		FB3.YB1~120	120	Byte signal output	
		FB3.YW1~60	60	Word signal output	
		FB3.YL1~30	30	Double word signal output	
		FB3.YF1~30	30	Float signal output	
	Controller input	FB3.X1~960	960	Bit signal input	
		FB3.XB1~120	120	Byte signal input	
		FB3.XW1~60	60	Word signal input	
		FB3.XL1~30	30	Double word signal input	
		FB3.XF1~30	30	Float signal input	

## 5.2. Assignment of output signals related to communication errors

Setting can be made in a way that the designated hard-wired output signal can be turned on when a PROFINET IO communication error occurs.

- (1) Select 『[F2]: System』 → 『2: Control parameter』 → 『2: Input/Output signal setting』 → 『4: Output signal assign』 .
- (2) After shifting using the 『[F4]: Previous』 or 『[F5]: Next』 key, enter the desired signal number in the “Fieldbus error” section, and then save the information using the 『[F7]: Complete』 key.




Figure 5.1 Communication error output signal assignment







- **Head Office**

Tel. 82-52-202-7901 / Fax. 82-52-202-7900  
1, Jeonha-dong, Dong-gu, Ulsan, Korea

- **A/S Center**

Tel. 82-52-202-5041 / Fax. 82-52-202-7960

- **Seoul Office**

Tel. 82-2-746-4711 / Fax. 82-2-746-4720  
140-2, Gye-dong, Jongno-gu, Seoul, Korea

- **Ansan Office**

Tel. 82-31-409-4945 / Fax. 82-31-409-4946  
1431-2, Sa-dong, Sangnok-gu, Ansan-si, Gyeonggi-do, Korea

- **Cheonan Office**

Tel. 82-41-576-4294 / Fax. 82-41-576-4296  
355-15, Daga-dong, Cheonan-si, Chungcheongnam-do, Korea

- **Daegu Office**

Tel. 82-53-746-6232 / Fax. 82-53-746-6231  
223-5, Beomeo 2-dong, Suseong-gu, Daegu, Korea

- **Gwangju Office**

Tel. 82-62-363-5272 / Fax. 82-62-363-5273  
415-2, Nongseong-dong, Seo-gu, Gwangju, Korea

- **본사**

Tel. 052-202-7901 / Fax. 052-202-7900  
울산광역시 동구 전하동 1번지

- **A/S 센터**

Tel. 82-52-202-5041 / Fax. 82-52-202-7960

- **서울 사무소**

Tel. 02-746-4711 / Fax. 02-746-4720  
서울특별시 종로구 계동 140-2번지

- **안산 사무소**

Tel. 031-409-4945 / Fax. 031-409-4946  
경기도 안산시 상록구 사동 1431-2번지

- **천안 사무소**

Tel. 041-576-4294 / Fax. 041-576-4296  
충남 천안시 다가동 355-15번지

- **대구 사무소**

Tel. 053-746-6232 / Fax. 053-746-6231  
대구광역시 수성구 범어 2동 223-5번지

- **광주 사무소**

Tel. 062-363-5272 / Fax. 062-363-5273  
광주광역시 서구 농성동 415-2번지