



**WARNING**

**INSTALLATION SHOULD ONLY BE  
PERFORMED BY QUALIFIED  
INSTALLATION PERSONNEL AND MUST  
CONFORM TO ALL NATIONAL AND  
LOCAL CODES**



## Manipulator Maintenance Manual

**HR050 / HR030L**





---

**The information presented in the manual is the property of HHI.  
Any copy or even partial is not allowed without prior written authorization from HHI.  
It may not be provided to the third party, nor used for any other purposes.**

**HHI reserves the right to modify without prior notification.**

**Printed in Korea - Dec. 2010. 2<sup>nd</sup> Edition  
Copyright © 2010 by Hyundai Heavy Industries Co., Ltd.**





# Contents

<b>1. Safety</b>	<b>1-1</b>
1.1. Introduction	1-2
1.2. Relevant Safety Regulations	1-4
1.3. Safety Training	1-4
1.4. Safety Related Nameplate	1-5
1.4.1. Safety Marking	1-5
1.4.2. Safety Nameplate	1-5
1.5. Definition of Safety Functions	1-6
1.6. Installation	1-7
1.6.1. Safety Fence	1-7
1.6.2. Placement of Robot & Peripheral Equipment	1-9
1.6.3. Installing the Robot	1-12
1.6.4. Space for Robot Installation	1-14
1.7. Safety Operation for Robot Handling	1-15
1.7.1. Safety Precautions for Robot Handling	1-15
1.7.2. Safety Precautions for Operating Test	1-17
1.7.3. Safety Precautions for Automatic Operation	1-18
1.8. Safety Precautions for Access to Safety Fence	1-19
1.9. Safety Precautions for Maintenance and Repair	1-20
1.9.1. Safety Precautions for Controller Maintenance and Repair	1-20
1.9.2. Safety Precautions for Robot System & Manipulator Maintenance	1-21
1.9.3. Necessary Actions after Maintenance and Repair	1-21
1.10. Safety Functions	1-22
1.10.1. Operating a Safety Circuit	1-22
1.10.2. Emergency stop	1-24
1.10.3. Operating Speed	1-25
1.10.4. Connecting the Safety Devices	1-25
1.10.5. Restricting the working Envelope	1-25
1.10.6. Monitoring Function	1-25
1.11. Safety Related to End Effectors	1-26
1.11.1. Gripper	1-26
1.11.2. Tool / Workpiece	1-26
1.11.3. Pneumatic and Hydraulic Systems	1-26
1.12. Liabilities	1-27
<b>2. Specifications</b>	<b>2-1</b>
2.1. Robot Machinery Part	2-2
2.2. Location of Robot Identification Plate	2-3
2.3. Basic Specifications	2-4
2.4. Robot Dimension and Working Envelope	2-6
2.5. Axis Identification	2-8
2.6. Details of Wrist Axis Attachment Surface	2-9
2.7. Details of Upper 1st ARM Attachment Surface	2-10
2.8. Application Wiring and Inspection Wiring Diagram	2-11
2.8.1. Details of Customer Application Connectors	2-12
2.9. Restricting the Working Envelope	2-13
2.9.1. Axis 1(Axis S)	2-13
<b>3. Instructions</b>	<b>3-1</b>

## Contents

<b>3.1. Robot Component Name .....</b>	<b>3-2</b>
<b>3.2. Location of Safety Nameplate .....</b>	<b>3-4</b>
<b>3.3. How to Transport.....</b>	<b>3-5</b>
3.3.1. Using Crane .....	3-5
3.3.2. Forklift use.....	3-7
<b>3.4. How to Install .....</b>	<b>3-9</b>
3.4.1. Operating Conditions .....	3-9
3.4.2. Installation the Robot Manipulator .....	3-9
3.4.3. Accuracy of Installation Surface .....	3-10
3.4.4. Dimension of Installation Surface .....	3-11
<b>3.5. Allowable Load of Wrist Axis .....</b>	<b>3-12</b>
3.5.1. Permitted load torque estimation .....	3-12
<b>3.6. Recommended Standby Posture .....</b>	<b>3-15</b>

## 4. Inspection

<b>4.1. Inspection Item and Period .....</b>	<b>4-2</b>
<b>4.2. Inspection Item and Period .....</b>	<b>4-3</b>
<b>4.3. Inspection of Main External Bolts .....</b>	<b>4-5</b>
<b>4.4. Inspection of Wrist Backlash .....</b>	<b>4-7</b>
<b>4.5. Inspection Internal Wiring .....</b>	<b>4-8</b>
4.5.1. The Conditions of Safety Inspection .....	4-8
4.5.2. Inspection Part .....	4-9

## 5. Maintenance

<b>5.1. Grease Replenishment/Replacement.....</b>	<b>5-2</b>
5.1.1. S-Axis Reduction Gear .....	5-3
5.1.2. H/V-Axis Reduction Gear .....	5-5
5.1.3. R2-Axis Reduction Gear .....	5-7
5.1.4. B/R1-Axis Reduction Gear .....	5-9
5.1.5. Bearing Joint Parts.....	5-11
<b>5.2. Battery Replacement .....</b>	<b>5-12</b>
5.2.1. Instructions for Battery Storage.....	5-14
<b>5.3. Internal Wiring .....</b>	<b>5-15</b>
5.3.1. Wiring Connection Diagram .....	5-16

## 6. Troubleshooting

<b>6.1. Troubleshooting Procedure .....</b>	<b>6-2</b>
<b>6.2. Trouble Symptoms and Possible Causes .....</b>	<b>6-3</b>
<b>6.3. Diagnostics and Resolutions for Major Parts Failure .....</b>	<b>6-4</b>
6.3.1. Fulcrum Bearings .....	6-4
6.3.2. Reduction Gear .....	6-5
6.3.3. Brakes .....	6-6
6.3.4. Motor .....	6-6
6.3.5. Encoder.....	6-7
<b>6.4. Motor Replacement .....</b>	<b>6-8</b>
6.4.1. Necessary Tools and Parts .....	6-9
6.4.2. How to Replace Motor .....	6-10
<b>6.5. Encoder Zero Setting .....</b>	<b>6-11</b>
6.5.1. Zero Setting.....	6-12
6.5.2. Encoder Reset .....	6-13

---

6.5.3. Encoder offset and Selection .....	6-14
---	------

<b>7. Recommended Spare Parts .....</b>	<b>7-1</b>
---	------------

<b>8. Internal Wiring Diagram .....</b>	<b>8-1</b>
---	------------

8.1. Manipulator Configuration .....	8-2
--------------------------------------	-----

8.2. Wiring Diagram .....	8-3
---------------------------	-----

<b>9. Decommissioning .....</b>	<b>9-1</b>
---------------------------------	------------

9.1. Material for each robot part.....	9-2
--	-----



### List of Figures

Figure 1.1 Recommended size for safety net and entrance gate (slot type entrance gate) ..	1-7
Figure 1.2 Recommended size for safety net and entrance gate (square type entrance gate)	1-7
Figure 1.3 Arrangement of LCD robot peripheral devices and workers .....	1-10
Figure 1.4 Arrangement of general robot peripheral devices and workers .....	1-11
Figure 1.5 Configuration for safety chain .....	1-22
Figure 1.6 Connection with external emergency halt switch through system board terminal block TBEM .....	1-24
Figure 2.1 Robot Machinery Part .....	2-2
Figure 2.2 The location of identification plate .....	2-3
Figure 2.3 Robot Dimension and Working Envelope: [HR050] .....	2-6
Figure 2.4 Robot Dimension and Working Envelope: [HR030L] .....	2-7
Figure 2.5 Robot Dimension and Axis [HR050/HR030L] .....	2-8
Figure 2.6 Details of Wrist Axis Attachment Surface : [HR050/HR030L] .....	2-9
Figure 2.7 Details of Upper 1st ARM Attachment Surface .....	2-10
Figure 2.8 Application Wiring and Inspection Wiring Diagram : [H050/HR030L] .....	2-11
Figure 2.9 Details of Application Connector : [HR050/HR030L] .....	2-12
Figure 3.1 Name of Robot Components : [HR050/HR030L] .....	3-2
Figure 3.2 Location of Safety Nameplate [HR050/HR030L] .....	3-4
Figure 3.3 How to Transport: Using crane [HR050] .....	3-5
Figure 3.4 How to Transport: Using crane [HR030L] .....	3-6
Figure 3.5 How to Transport : Using forklift [HR050] .....	3-7
Figure 3.6 How to Transport : Using forklift [HR030L] .....	3-8
Figure 3.7 Accuracy of Installation surface .....	3-10
Figure 3.8 Dimension of Robot Installation : [HR050/HR030L] .....	3-11
Figure 3.9 Wrist Axis Torque Mapping:[HR050] .....	3-14
Figure 3.10 Wrist Axis Torque Mapping:[HR030L] .....	3-14
Figure 3.11 Recommended Standby Posture .....	3-15
Figure 4.1 Inspection Part for Main Bolts [HR050/HR030L] .....	4-6
Figure 4.2 Abnormal Backlash Inspecting Directions [HR050/HR030L] .....	4-7
Figure 4.3 Cable Inspection Parts .....	4-9
Figure 5.1 Location of Battery Replacement .....	5-13
Figure 5.2 Explains of internal wiring .....	5-16
Figure 6.1 Method of Zero Setting [HR050/HR030L] .....	6-12
Figure 8.1 Manipulator Configuration .....	8-2
Figure 8.2 Cabling diagram [HR050/HR030L] .....	8-3
Figure 8.3 Motor Power Cable [HR050/HR030L] .....	8-4
Figure 8.4 Axis S & H, Encoder Wiring Connection [HR050/HR030L] .....	8-5
Figure 8.5 Axis V & R2, Encoder Wiring Connection [HR050/HR030L] .....	8-6
Figure 8.6 Axis B & R1, Encoder Wiring Connection [HR050/HR030L] .....	8-7
Figure 8.7 Application Wiring Connection 1 [HR050/HR030L] .....	8-8
Figure 8.8 Application Wiring Connection 2 [HR050/HR030L] .....	8-9



---

## List of Tables

Table 1-1 Safety marking .....	1-5
Table 1-2 State of Robot Stop .....	1-16
Table 2-1 Basic Specifications for Models: [HR050/HR030L] .....	2-4
Table 2-2 Axis Motion .....	2-8
Table 3-1 Components name : [HR050/HR030L] .....	3-3
Table 3-2 Allowable load weight .....	3-12
Table 3-3 Allowable Load Torque .....	3-12
Table 3-4 Allowable Load Torque .....	3-12
Table 4-1 Inspection Schedule .....	4-2
Table 4-2 Inspection Items and Periods .....	4-3
Table 4-3 Inspection part for main bolts .....	4-5
Table 6-1 Trouble phenomenon and cause .....	6-3
Table 6-2 Necessary Tools .....	6-9
Table 6-3 Necessary parts and zero point setting method by axis .....	6-9
Table 7-1 Spare Parts List I .....	7-2
Table 9-1 Materials of each part .....	9-2







**HYUNDAI**  
HEAVY INDUSTRIES CO., LTD.

1

**Safety**




# 1. Safety

HR050/HR030L

## 1.1. Introduction

The main purpose of this chapter is to describe the safety precautions for users and operators who repair and manipulate the industrial robot.

This manual describes safety precautions for robot manipulator and controller, in compliance with the safety regulation of EU Machinery Directive 98/36/EC(2006/42/EC) and US OSHA. And the robot manipulator and controller is manufactured to comply with the safety standards EN ISO 10218-1:2006 and ANSI/RIA R15.06-1999.

Every operator, who installs, replaces, adjusts, manipulates, maintains, and repairs, must read thoroughly and fully understand the manipulation and maintenance manual, in particular, the special attention must be paid to the  symbol, the most important marking related to the safety.

Installation, replacement, adjustment, manipulation, maintenance, and repair of robot system must be performed by the personnel who was duly trained for these purposes, following the indicated operating procedure.

This company is planning and carrying out the relevant training such as maintenance, repair, and manipulation for the above operations, so robot users make sure that robot operators should get the relevant training. And make sure that the robot handling work should be carried out only by the operators who completed this training course.

HHI user of industrial robot has responsibility to observe the safety regulation related to robot adopted in corresponding countries and responsibility to design, install and operate safety equipment well in order to protect workers who work at robot system.

The dangerous zone of robot system, that is the working range in which the robot, tool, and peripheral equipment are operated, must be safeguarded to prevent workers or objects from entering the zone. If a person or object should nevertheless enter the dangerous zone, make sure that the robot system is immediately shut down by emergency stop system. The operators of robot system have a responsibility to take all necessary steps to make correct installation, examination and operation of the relevant safety devices.

Enable application and disable environment of robots are as follows.

### ▶ Application

It is applied to the industrial robot used by installing on the surface of wall or plane (axes addable). It is also appropriate for controlling operation in the dotted section or consecutive section.

Major application is

- Spot welding
- Arc welding
- Cutting
- Handling
- Assembly
- Application such as Sealing
- MIG/MAG welding
- Palletizing
- Grinding

For the other use than the above emergency application, make a contact with our company to consult on the robot use and possible applications.

### ▶ Disable environment

Our robot must not be used in a highly explosive environment and the areas contaminated by oil, flammable materials or chemical materials. (Prohibited to be installed and manipulated.)

## 1.2. Relevant Safety Regulations

The robot is designed as per ISO 10218-1:2006 safety standards for industrial robots, and furthermore in comply with ANSI/RIA 15.06-1999 regulations.

## 1.3. Safety Training

All the personnel who intend to teach, operate or inspect the robot must be trained in an approved robotic operation and safety training course before start-up. The safety training course includes the following details:

- Purpose and functions of safety devices
- Safety procedure to handle the robot
- Performance of robot or the robot system and possible hazards
- Tasks associated with any specific robot applications
- Safety concepts, etc.






## 1.4. Safety Related Nameplate

### 1.4.1. Safety Marking

For the purpose of effective safety instructions, the following safety symbols are used in this manual.

Table 1-1 Safety marking

Symbols		Descriptions
Warning		Indicate a potentially hazardous situation which, if not avoided, could result in death or serious injury to personnel and damage to equipment. The special attention must be paid to the operation and handling.
Mandatory		Indicate the compulsory measures that should be performed.
Prohibited		Indicate the prohibited actions and/or operations that should not be performed.

### 1.4.2. Safety Nameplate

Identification plates, warning label and safety symbols are attached to the robot and to the inside and outside of control panel. The designation labels and cable Mark for wire harness between the robot and control panel, and the cables inside/outside of control panel are provided.

All of these plates, labels, symbols and marks constitute safety-relevant parts of the robot and the control panel. They must remain attached to the robot manipulator and control panel at their clearly visible positions all the time for the safety and their full performance.

The painted markings on the floor and signs indicating dangerous zones must be clearly distinguished in form, color, and style from other markings on the machine near the robot system or inside the plant facilities where the robot system is installed.



**It is forbidden to remove, cover, or paint over by way of spoiling the clearly visible identification plates, warning labels, safety symbols, designation labels and cable marks.**

## 1.5. Definition of Safety Functions

### ▶▶ Definition of Safety Functions - IEC 204-1,10,7

There is one emergency stop button on the controller and teach pendant respectively. If necessary, additional emergency buttons should be able to connect to the robot's safety chain circuit. The emergency stop function, which overrides all other robot controls, stops all moving parts by disconnecting power supply, and removes drive power to prevent the use of other dangerous functions controlled by the robot.

### ▶▶ Safety Stop Function - EN ISO 10218-1:2006

When a safety stop circuit is provided, each robot must be delivered with the necessary connections for the safeguards and interlocks associated with this circuit. The robot should have a number of electrical input signals which can be used to connect external safety devices, such as safety gates, safety pads, and safety lamps. These signals allow the robot's safety functions to be activated by all equipment, including peripheral equipment and the robot itself.

### ▶▶ Speed Limitation Function - EN ISO 10218-1:2006

In a manual mode, the speed of robot is strictly limited to 250 mm per second as maximum. The speed limitation applies not only to the TCP (Tool Center Point), but to all parts of manual mode robot. The speed of equipment mounted on the robot should be possibly monitored.

### ▶▶ Restricting working Envelope - ANSI/RIA R15.06-1999

Operation area of each axis is restricted by soft limit and hardware limit. Axis 1, 2, and 3 can also be restricted by means of mechanical stopper.

### ▶▶ Operation Mode Selection - ANSI/RIA R15.06-1999

The robot must be operated either manually or automatically. In a manual mode, the robot must be operated only by using the teach pendant.



## 1.6. Installation

### 1.6.1. Safety Fence



**Install safety fence against the possible collision between the robot and workers, so that no worker may approach the robot.**

Install safety fence against the possible collision between the robot and workers, so that no worker may approach the robot. When operators or other personnel enter the robot's working envelope by accident, it may cause an accident. Install the safety fence to stop the robot when one, who intends to replace for TIP DRESSING or TIP changing replacement, or to inspect welding equipment, opens the fence gate and approaches the equipment during operation.




Figure 1.1 Recommended size for safety net and entrance gate (slot type entrance gate)




Figure 1.2 Recommended size for safety net and entrance gate (square type entrance gate)

- (1) Enough space for safety net should be secured by covering robot operating area so as that workers would not have difficulty in teaching work or repairing work, and the safety net should have solid structure in order that it would not move easily and man cannot enter over easily.
- (2) Safety net should be installed by static type in principle, and should not have hazardous parts such as prominence and depression or keen part, etc.
- (3) Install the safety fence with an entrance gate, and register the safety plug at the gate so that it does not open unless pulling the plug out. And, please make wiring with interlock so that robot would be operation ready OFF and motor OFF in the status that safety plug is pulled out or safety net is open.
- (4) When intending to operate the robot with the safety plug pulled out, wire the robot as a low-speed play mode.
- (5) For immediate emergency stop, install emergency stop button within operator's easily accessible distance.
- (6) In case of no safety net, please install photoelectric switch, mat switch and so on instead of safety plug in all range of robot operation, and make robot to stop automatically when man goes into.
- (7) Operation area of robot (hazardous area) should be distinguished by the method like painting on floor.



### 1.6.2. Placement of Robot & Peripheral Equipment



**Please make sure that robot and peripheral equipment should be arranged by following method.**

- (1) In case of connecting primary power of controller or peripheral devices, please work after checking whether supply power has been deleted. There is a possible danger of electric shock because the high voltage such as 220V and 440V is used as its primary power.
- (2) Post a sign [No enter during operation] up the safety fence gate, and inform the operators of its purport.
- (3) Arrange such devices as controller, interlock panel, and other manipulation panels to be handled outside of the safety fence.
- (4) When installing operation stand, install the emergency stop button on the stand. Make sure that the stand stops in an emergency wherever the robot is handled.
- (5) Make sure that the robot manipulator and the wiring and piping of controller, interlock panel, and timer should not be placed in the way of operator's working range so that they would not be directly stepped on by FORK and LIFT. The accident by falling down of work or wire cut can happen.
- (6) Place the controller, interlock panel, and handling stand within the sight of robotic performance. It may cause a serious accident to operate the robot while the operator is working, or the robot is malfunctioning in an invisible sight.
- (7) Restrict the robot's working envelope by using soft limits and mechanical stopper if the necessary working envelope is narrower than the holding workable envelope. It is possible to stop the robot in advance when it moves beyond its normal working envelope due to an abnormal condition. (Refer to the 『Robot Manipulator Maintenance Manual』 .)
- (8) During weld, spatter can fall down to workers or the workers can be injured by burning, or fire can break out. Install such devices as a glare shield or a cover in the full sight of robot's working envelope.
- (9) Make sure that the device indicating the robot's running condition whether automatic or manual mode must be noticeable even in the far distance. In the case of automatic start-up, warning with a buzzer or warning lamp is also enable.
- (10) Make sure that there is no projecting part in the robot's peripheral equipment. Cover it, if necessary. It usually may cause an accident if the operator comes in touch with it. And it may lead a serious accident if the operator is astonished at the sudden movement of robot, and conducts it.
- (11) Don't make the system designed to allow the workers to carry the Work in and out using their hands through the safety fence. It could be a cause of accident associated with compressing or amputating.




Figure 1.3 Arrangement of LCD robot peripheral devices and workers




Figure 1.4 Arrangement of general robot peripheral devices and workers

### 1.6.3. Installing the Robot



**Please install the robot in accordance with following method surely.**

Install the robot as per the planning and layout which has been previously reviewed and studied for its optimized performance and functionality. In case of poor conditions for robot installation, the serious problems can take place, including error of relative position between robot and workpiece during operation, bad performance quality of robot caused by vibration, shortening lifetime, and cause of serious accidents. Thus, pay attention to the following precautions when installing the robot.

#### **General Safety Precautions**

- (1) Design and install the robot system properly in compliance with laws, regulations, and safety requirements enable in the country where the robot system is installed.
- (2) All the workers for the robot system must have the complete knowledge on the information specified in the application and supplementary manual, and proficiently operate and handle the industrial robot.
- (3) Installation workers of robot must follow the safety instructions and apply them to the installation when they face any safety problems.
- (4) System provider must ensure that all the circuits utilizing safety functions perfectly perform in a safe way.
- (5) Install main power supply to be disconnected from outside of the robot's working envelope.
- (6) System provider must ensure that all the circuits utilizing emergency stop function perfectly perform in a safe way.
- (7) For the immediate emergency stop, install emergency stop button within the accessible distance for the operator.

### Technical Safety Precautions

- (1) Eliminate any interference with peripheral equipment considering the dimension and working envelope.
- (2) Avoid such place for installing which is directly exposed to the sun, extremely humid, contaminated by oil or chemicals, and containing a large amount of metal powder and explosive gas.
- (3) Install at the ambient temperature ranged 0~45℃.
- (4) Secure sufficient space for the easier disassembly and maintenance.
- (5) Install safety fence with a gate, and prohibit any person from entering the robot's working envelope.
- (6) Remove any obstacles out of the robot's working envelope.
- (7) Take a special measure, considering thermodynamics of controller, if the robot is installed near the heating elements or places exposed directly to the sun.
- (8) Take a special measure if the robot is installed in a place of abundant dust such as metal powder in the air.
- (9) Install the robot not to transmit welding electric current. In other word, insulate SPOT GUN with/from the robot's wrist.
- (10) Grounding is very critical in preventing electric shock and malfunction caused by noise, and thus install as following instructions.
  - ① Install an exclusive grounding terminal using class 3 or higher. (For the input voltage of 400V or higher, use special class 3 or higher.)
  - ② Connect grounding line into the grounding bus-bar inside of the control panel.
  - ③ In case of direct grounding on the floor by anchoring, two-point grounding both by robot manipulator and by controller can produce a "ground loop" and contrariwise cause abnormal operation. In this case, connect the grounding line to the base of robot manipulator and disconnect the second grounding point to the controller. If the robot vibrates even after stopping, double-check the grounding status because the possible main causes could be an incomplete grounding or "ground loop".
  - ④ In the use of internal transgun(GUN), there is a possible danger of dropping because the primary power cable is directly connected to the spot gun. In this case, directly connect the grounding line to the base of robot manipulator in order to prevent any electric shock and protect the control panel, but do not connect it to the controller.

#### **1.6.4. Space for Robot Installation**

Install robot after securing sufficient space for maintaining the robot manipulator, controller, and other peripheral equipment. To install the main body and controller, please secure the above mentioned installation area. Install controller outside of the safety fence in order to monitor the robot manipulator and to operate in a safe way.

When installing, be sure to make it easier to perform the maintenance when opening the Controller door. Secure the available space. The specifications of the controller can change according to the type of the controller. (For more details, please refer to the “Maintenance manual”.)





### 1.7. Safety Operation for Robot Handling

Follow the safety instructions to prevent any accidents. Don't modify nor ignore safety devices or circuits at any time, and be careful of electric shock.

All the normal operations in an automatic mode must be performed outside of the safety fence. Check the robot's working envelope if anyone is inside before operating.

#### 1.7.1. Safety Precautions for Robot Handling



**Please observe following countermeasures because safety is very important on operation of robot.**

- (1) Do not handle the robot other than such personnel as operators handling the robot and other possible operators and supervisors who were designated as whom duly trained in an approved robotic training course and become familiar enough with the proper operation of the safety and robotic functions.
- (2) Be sure to wear helmets, goggles, and safety shoes.
- (3) Perform the work in pairs. One person must be ready to press the emergency stop button in an emergency while the other must perform his work quickly but carefully within the robot's working envelope. Always check the escape route before working.
- (4) Make sure that there is no one in the working envelope when the power source is on.
- (5) Operations such as teaching must be performed outside of the robot's working envelope. However, if the operation is performed within the working envelope after stopping the robot, enter the envelope with safety plug or key switch for converting to automatic mode. Make sure that other operators do not change it into automatic mode by accident. Also, pay close attention to the specific direction of robotic movement in case of abnormal operation and malfunction.
- (6) Supervisors should follow the instructions below.
  - ① Be located at a place where you could take an entire view of robot, and commit yourself to monitoring.
  - ② Press the emergency stop button immediately when abnormality is found.
  - ③ Anyone is forbidden to be near the operating area other than those who are engaged in the operation.
- (7) In a manual mode, the speed of teaching is limited to 250mm/sec.
- (8) In teaching, post a sign [Under Teaching].
- (9) Operators must pull the safety plug out, and enter the safety fence with the plug.
- (10) Do not use any devices causing noise in and around the teaching area.
- (11) Handle the teach pendant button, while checking the teaching point with your naked eyes, and do not handle it just relying on your sense.



- (12) It is a repairing part to be prepared for when you buy many sets.

- (13) In teaching, check and examine carefully under your feet. In particular, in high teaching for more than 2M, secure a safe zone on which you may step before teaching.



- (14) Instructions for any abnormal operations.

- ① Press immediately the emergency stop button when any abnormal operations are found.
- ② Be sure to check if the relevant equipment is stopped when checking the abnormality in an emergency stop.
- ③ In case that the robot stops automatically due to power failure, investigate possible causes and take actions after confirming that the robot completely stops.
- ④ In case of malfunction of emergency stop devices, immediately disconnect the main power and investigate possible causes to take necessary actions.
- ⑤ Investigation of the failure must be conducted only by a designated person. For the re-operation after emergency stop, operators must clarify the cause of failure and take necessary actions, and then operate the robot again following the proper procedure.

- (15) Write out the operating rules proper to working details and installing location regarding the operation and handling method for the robot, and the necessary actions for robot's any failure. In addition, it is recommended to operate the robot in accordance with the operating rules.

- (16) Instructions when the robot stops

Make sure not to approach the robot even when it seems to be stopped. Most accidents occur from a sudden movement of robot which seemed to be stopped when one approaches it. The conditions that the robot stops are as follows.

Table 1-2 State of Robot Stop

No.	State of Robot	Drive Power	Access
1	Pause (Minor failure, Pause switch)	ON	X
2	Emergency stop (Major failure, Emergency stop switch, Safety gate)	OFF	O
3	Input signal standby of peripheral equipment (START INTERLOCK)	ON	X
4	Playback Completion	ON	X
5	Standby	ON	X

Even in the accessible state of robot, be watchful against any possible sudden movement of robot. Make sure to avoid approaching the robot without precautions for emergency under all circumstances.

- During temporary halt, the entrance countermeasure same as entrance of teaching work should be considered at the case (nozzle contact, welded part detected, arc error, and so on) of opening entrance gate for simple management against error.

- (17) Clean up any split oil, tools, and impurities in the safety fence after completing robotic operation. Accidents such as conduction may occur in the working envelope contaminated by oil, or scattered tools on its floor. Make a habit of organizing and cleaning things up.

### 1.7.2. Safety Precautions for Operating Test



**Please observe following countermeasures because safety on robot operation is very important.**

In case of operating test, errors in design or teaching and inferiority in manufacturing are possibly seen in the entire system such as teaching program, jig, and sequence. Thus, be more careful and safe in case of operating test. Accidents may occur by these combined causes.

- (1) Before handling, check the stop buttons and signal functions to stop the robot such as emergency stop button or stop button. And then, check the abnormality - detective movements. Above all, it is the most critical to check all the stop signals. It would be the most important to stop the robot when any possible accidents are predicted.
- (2) In case of operating test, start the robot at low speed (approximately 20%~30%) in the variable speed function, and repeat it more than one cycle to check the movements. If any errors are found, immediately correct them. After then, increase in speed (50% → 75% → 100%) gradually, and repeat more than one cycle respectively to check the movements. Operating at high speed from the very beginning may cause a serious accident.
- (3) In case of operating test, it is hard to predict what problems would happen. Do not enter the safety fence during operating test. Unexpected accidents are likely to occur because of its low reliability.

**HYUNDAI**  
HEAVY INDUSTRIES CO.,LTD.

### 1.7.3. Safety Precautions for Automatic Operation



**Please observe following countermeasures because safety on robot automatic operation is very important.**

- (1) While posting a sign [Do Not Enter During Operation] up the safety fence gate, ask the operators not to enter during operation. If the robot stops, you may enter the safety fence under your full understanding of the situation.



- (2) Be sure to check if any operators are inside of the safety fence when starting the automatic operation. Operating without checking the presence of operators may cause a personal injury.
- (3) Before starting the automatic operation, check and confirm that the program number, step number, mode, and starting selection are in the possible state for automatic operation. If starting with the other programs or steps selected, the robot could move in an unpredicted way, and lead to an accident.
- (4) Before starting the automatic operation, check if the robot is properly located to get started. Check whether the program number or step number is identical with the location of robot. Even if it's all identical, accidents are still possible to occur due to an abnormal movement when the robot is differently located.
- (5) Be prepared to immediately press the emergency stop button when starting the automatic operation. Immediately press the emergency stop button in case of robot's unexpected movements or emergency.
- (6) Be sure to detect any abnormalities by checking the route, condition, or sound of robot movement. Sometimes the robot may be abnormally operated including a sudden break down. However, it will show a certain indication before the break down. Understand the robot's normal condition well in order to catch the symptom in advance.
- (7) When any abnormality is detected from the robot, immediately stop and take proper actions on it. Using the robot before any proper actions taken may cause an interruption of produce as well as serious failure leading to a very serious personal injury.
- (8) When checking the robot's movement after the proper actions taken for the abnormality, do not operate the robot with operators inside of the safety fence. Unexpected accidents are possibly to occur because its low reliability may cause another abnormality.

### 1.8. Safety Precautions for Access to Safety Fence



Please observe following countermeasures because safety on entering into safeguard is very important.

The robot is very heavy and strong, even at low speeds. When entering the safety fence, one must observe the relevant safety regulations of its pertinent country.

The operators always must be aware of the unexpected movements of robot. Robots are able to move fast shortly after being stopped. The operators should know that the robot is able to move in a different route, without any notice, by means of external signals. Thus, when trying to stop the robot during teaching or operating test, one should be able to stop the robot with a teach pendant or control panel.

When entering the working envelope through the safety gate, take the teach pendant with you so that other people may not operate the robot. Make sure to post up the control panel a sign indicating the state of robot handling.

Read carefully and be aware of the follows when entering the working envelope.

- (1) Do not enter the working envelope other than teaching person.
- (2) Operation set-up mode of controller must be a manual mode in the control panel.
- (3) Always wear the approved working suite. (Do not wear a loose clothes as you please)
- (4) Do not wear gloves when handling controller.
- (5) Do not leave innerwear such as underwear, shirts, or necktie out of the working suite.
- (6) Do not wear personal accessories such as big earrings, rings, or necklaces.
- (7) Make sure to wear safety shoes, helmet, and goggles and if necessary, wear other self-protective outfit such as safety gloves.
- (8) Make sure that the emergency stop circuit is working correctly and in its proper function, turns MOTOR OFF when pressing the emergency stop button in the control panel and teach pendant before handling the robot.
- (9) Make your posture face-to-face with the robot manipulator when performing your work.
- (10) Follow the predetermined working procedure.
- (11) Be prepared for emergency exit or safe place considering that the robot may unexpectedly rush at you.

## 1.9. Safety Precautions for Maintenance and Repair

### 1.9.1. Safety Precautions for Controller Maintenance and Repair



**Please observe following safety countermeasures on repair and check for robot controller.**

- (1) Maintenance and repair of the robot must be performed by the personnel who was duly trained in the special maintenance training course and has a good knowledge of maintenance.
- (2) Perform your work following the maintenance procedures for controller.
- (3) Perform your maintenance and repair in a safe way by securing emergency exit or safe place.
- (4) Before the daily maintenance, repair, or changing parts, be sure to power down. In addition, post a warning sign [Do Not Input Power] up the primary power so that other operators may not input power by accident.
- (5) When changing parts, be sure to use the specified ones.
- (6) When you open the door of controller, you should turn off power, and please start working after 3 minutes.
- (7) Please do not touch heat radiating plate of servo AMP and recovery resistance because they are very hot.
- (8) After completing maintenance, be sure to close the door completely after checking if tools or other things are still remained in the controller.

### 1.9.2. Safety Precautions for Robot System & Manipulator Maintenance



**Please observe following safety countermeasures on repair and check for robot controller.**

- (1) Refer to the safety precautions for Controller maintenance and repair.
- (2) Perform your maintenance and repair for the robot system and manipulator, following the indicated procedures.
- (3) Be sure to disconnect the primary power of controller. Post the warning sign [Do not input power] up the primary power to prevent other workers from connecting the power.
- (4) Make sure that the Arm is fixed and immovable before maintenance and repair since dropping or moving of the robot's Arm may cause a danger during maintenance and repair. (Refer to the 『Robot manipulator maintenance manual』 .)

### 1.9.3. Necessary Actions after Maintenance and Repair



**Please observe following managing articles after the repair and check.**

- (1) Check if the cables or parts of controller are properly connected.
- (2) After maintenance is completed, carefully check that no tools are left around or inside of the controller and manipulator. Make sure that the door is firmly closed.
- (3) Do not turn on the power if any problems or critical failures are detected.
- (4) Be sure that there is no one within the working envelope, and that you are in a safe place before turning on the power.
- (5) Turn on the main circuit breaker on the control panel.
- (6) Check the current position and status of robot.
- (7) Operate the manipulator at low speed.

## 1.10. Safety Functions

### 1.10.1. Operating a Safety Circuit




Figure 1.5 Configuration for safety chain

The robot's safety system is based on a two-channel safety circuit that is continuously monitored. If an error is detected, the power supply to the motors is disconnected and the motor brake is applied. To return the robot to MOTOR ON mode, the switches of two-channel circuit must be connected. If one of the two-channel circuit switches shorts, the contactor of motor will be disconnected leading to the application of brake, and finally the robot will be stopped. Furthermore, when safety circuit is disconnected, the interrupting call will be sent automatically to the controller to find out the possible reason for the interruption.

The safety control circuit of operation is based on dual safety electric circuit in which the controller and MOTOR ON mode are operated interactively. In order to be in MOTOR ON mode, the safety circuit consisted of several switches must be all connected. MOTOR ON mode indicates that drive power is supplied to the motors. If one of the contactors is disconnected, the robot will always return to MOTOR OFF mode. MOTOR OFF mode indicates that drive power is removed from the robot's motors and the brakes are applied. The status of the switches is displayed on the teach pendant. (Refer to the I/O monitoring screen of "SERVICE" menu, 『operation manual』.)



### Safety circuit

The emergency stop buttons on the controller panel and on the teach pendant and external emergency stop buttons are included in the safety circuit of operation. Users may install the safety devices (safety plug, safety stop device for safe place) which are operated in the AUTO mode. In a manual mode, the signals of these safety devices are ignored. You can connect the general safety stop devices that is active in all operating modes. No one can enter the working envelope in an automatic operation mode due to the unconditional operation of the safety devices (door, safety mat, safety plug etc.). These signals are also generated in a manual mode, but the controller will keep the robot operating while ignoring the robot's teaching. In this case, maximum speed of robot is restricted to 250mm/s. Thus, the purpose of this safety stop function is to secure the safe area around the manipulator while one approaches the robot for maintenance and teaching.

When the robot is stopped with the limit switch, change the robot's position by operating it with the pendant key at the constant setting mode. (Constant setting mode refers to the status in the menu: “『F2』: System』 → 『3. Robot parameter』 → 『2. Axis constant』 / 『3. Soft limit』 / 『4. Encoder offset』 ”.)



**The safety circuits must never be by-passed, modified or changed in any way.**



### 1.10.2. Emergency stop

An emergency stop should be activated when people or equipment is located at the dangerous area. The emergency stop buttons are located both on the control panel and on the teach pendant. All safety control devices such as emergency stop buttons on the control panel must be located outside the working envelope and easily accessible at any time.

#### ► Status of Emergency stop

When the button is pressed, the robot will operate as follows.  
Robot stops immediately in any cases.

- Disconnect the servo system power.
- Motor brake is activated.
- Emergency stop message is displayed on screen.

For the emergency stop, the following two methods can operated simultaneously.

- (1) Emergency stop for control panel and teach pendant (Basic)

Above the control and teach pendant console.

- (2) Emergency stop of external system

External emergency stop device (button etc.) can be connected to the safety electric circuit in accordance with applied standard for the emergency stop circuit.

(Please refer to system board in “basic configuration of controller”) At this time, the emergency stop must be connected to be “Normal On” and it must be check for proper operation during test run.




Figure 1.6 Connection with external emergency halt switch through system board terminal block TBEM

### 1.10.3. Operating Speed

To teach the robot, the operating mode switch must be in a MANUAL mode. Then the maximum speed of robot is limited to 250mm/s.

### 1.10.4. Connecting the Safety Devices

External safety devices such as light beams, light curtains, safety plug, and safety mats which can be adapted by the system builder execute interlocking the controller by way of connecting with safety circuit within the controller. These devices are used for safety device during execution of normal program in an automatic mode.

### 1.10.5. Restricting the working Envelope

When the robot is not necessary to reach certain area for specific applications, working envelope of the robot can be limited to secure the sufficient safety working area. This will reduce the damage or loss in case of robot's collision with external safety devices such as safety fence, etc. The movement of axes 1, 2, and 3 of HR, HX, HS and HA can be limited by means of mechanical stopper or electrical limit switches. In this case, the corresponding software limitation parameters must be also changed. If necessary, movement of wrist 3 axes can be restricted, too. Limitation of working envelope for all the axes could be carried out by the user. The robot is delivered to customer as the status of full working envelope setting

- **Manual mode: Maximum speed is 250mm/s.**  
In a manual mode, by means of worker's selection, workers may enter the safeguard area.
- **Auto mode : The robot can be operated via remote controller.**  
All safety devices such as safety door, safety mats, etc. are activated.  
No one may enter the safety device area of robot.

### 1.10.6. Monitoring Function

- (1) Motor monitoring function  
Motors are protected against overload by means of onboard sensors.
- (2) Voltage Monitoring Function  
For the protection of, the servo amp module turns off the power switch when the voltage is too low or too high.


## 1.11. Safety Related to End Effectors

### 1.11.1. Gripper

- (1) When a gripper is used to grip a workpiece, there should be safety precautions for unexpected dropping of the loaded workpiece.
- (2) When any end effectors or devices are installed on the robot arm, use the required size and piece of bolt, and securely fasten as per the required torque using torque wrench. Do not use the bolt which has rust or dirt on its surface.
- (3) End effector must be designed and manufactured not to exceed the maximum allowable load at the wrist of robot. Even though power or air supply stops, the gripped workpiece must not be dropped from the gripper. In order to remove any risks and problems which may cause personal injury and/or physical damage, the sharp edge and projecting part of end effector must be made dull and smooth.

### 1.11.2. Tool / Workpiece

- (1) It must be possible to replace tools such as milling cutters in a safe manner. Make sure that safety devices are working correctly until the cutters stop rotating.
- (2) Tool must be designed to keep in gripping workpiece securely even though a power failure or a control failure takes place. It must be possible to release workpiece from the gripper in a manual mode.

 **HYUNDAI**  
HEAVY INDUSTRIES CO.,LTD.

### 1.11.3. Pneumatic and Hydraulic Systems

- (1) The special safety regulations will apply to pneumatic and hydraulic systems.
- (2) Since residual energy of pneumatic and hydraulic systems can be still remaining even after the robot stops, particular care and attention must be paid by users. Internal pressure of equipment must be removed whenever starting the repair work for pneumatic and hydraulic systems.

### 1.12. Liabilities

The robot system has been built in accordance with the latest technical standards and approved safety rules. Nevertheless, the serious accidents such as death or personal injury still may take place due to the collision between the robot system and peripheral equipment.

The robot system must be used by operator who has a full technical knowledge on its designated use and also pay his close attention to the possible dangers and risks involved in its operation. The use of robot system is subject to compliance with these operating instructions and the operation and maintenance manual supplied together with the robot system. The safety related functions of robot system must not be used for any purposes other than safety.

When you use the robot system for any other or additional purposes than its designated usage, you must review whether it is enable in accordance with design criteria. The manufacturers cannot take any responsibility for any damage or loss which resulted from such misuse or improper use. The users shall have the full responsibility for the risks caused by such misuse or improper use. When you use and operate the robot system for its designated use, you must have a good command of all the information contained at these operating instructions as well as the maintenance manual.

The robot system may not be put into operation until it is ensured that the functional machine or plant into which the robot system has been integrated conforms to the specifications of the EU Machinery Directive 98/37/EC(2006/42/EC) and US OSHA.

The following harmonized standards in particular were taken into account with regard to the safety of the robot system.

- ANSI/RIA R15.06-1999  
Industrial Robots and Robot Systems - Safety Requirements
- ANSI/RIA/ISO 10218-1-2007  
Robots for Industrial Environment - Safety Requirements - Part 1 - Robot
- ISO 11161:2007  
Safety of machinery - Integrated manufacturing systems - Basic requirements
- EN ISO 13849-1:2008  
Safety of machinery - Safety-related parts of control systems - Part 1: General principles for design (ISO 13849-1:2006)
- EN 60204-1:2006  
Safety of machinery - Electrical equipment of machines - Part 1: General requirements (IEC 60204-1:2005 (Modified))
- EN ISO 10218-1:2006  
Robots for industrial environments - Safety requirements - Part 1: Robot (ISO 10218-1:2006)

Users must take the full responsibility for any accident caused by their negligence or non-observance of these instructions. The manufacturer will not take any liabilities and responsibilities for any damages or losses caused by the misuse or malfunction of such equipment which is not included in the contract between manufacturer and user and provided by user, or such equipment which is installed around the robot system arbitrarily by the user. User must take the full liabilities and responsibilities for any risks and damages caused by such equipment.





**HYUNDAI**  
HEAVY INDUSTRIES

2

Specifications



## 2. Specifications

HR050/HR030L

### 2.1. Robot Machinery Part





Figure 2.1 Robot Machinery Part





### 2.2. Location of Robot Identification Plate

The model name, serial number, and manufacturing date of robot are written down in the name plate. The name plate is located at the lower part of the main body (left or right) as shown below.




Figure 2.2 The location of identification plate

## 2.3. Basic Specifications

Table 2-1 Basic Specifications for Models: [HR050/HR030L]

Item				Specification	
Model				HR050	HR030L
Construction				Articulated	
Degree of freedom				6	
Drive system				AC servo system	
Max. Working envelope	Arm	S	Swivel	±3.142 rad (±180°)	
		H	For/Backward	+2.62 ~ -1.34 rad (+150°~ -77°)	
		V	Up/ downward	+2.34 ~ -2.36 rad (+134°~ -135°)	
	Wrist	R2	Rotation 2	±6.283 rad (±360°)	
		B	Bending	±2.217 rad (±127°)	
		R1	Rotation 1	±6.283 rad (±360°)	
Max. Speed	Arm	S	Swivel	2.618 rad/s (150°/s)	2.443 rad/s (140°/s)
		H	For/Backward	2.967 rad/s (170°/s)	2.618 rad/s (150°/s)
		V	Up/ downward	2.967 rad/s (170°/s)	2.618 rad/s (150°/s)
	Wrist	R2	Rotation 2	4.363 rad/s (250°/s)	3.662 rad/s (210°/s)
		B	Bending	4.363 rad/s (250°/s)	3.662 rad/s (210°/s)
		R1	Rotation 1	6.109 rad/s (350°/s)	5.236 rad/s (300°/s)
Load Capacity				490 N (50 kg)	294 N (30 kg)
Wrist Torque		R2	Rotation 2	177 N·m (18 kgf·m)	117.6 N·m (12 kgf·m)
		B	Bending	177 N·m (18 kgf·m)	117.6 N·m (12 kgf·m)
		R1	Rotation 1	88 N·m (9 kgf·m)	58.8 N·m (6 kgf·m)
Accuracy of position repeatability				±0.15 mm	

## 2. Specifications

Item	Specification	
Model	HR050	HR030L
Ambient Temperature	0 ~ 45 °C (273 ~ 318 K)	
Relative humidity	20 ~ 85 %RH	
Robot's Weight	650 kg	670 kg
Working envelope section area	4.94 m <sup>2</sup>	6.82 m <sup>2</sup>



## 2.4. Robot Dimension and Working Envelope





Figure 2.3 Robot Dimension and Working Envelope: [HR050]



## 2.5. Axis Identification

Table 2-2 Axis Motion

Axis Name	Operation	Teach Pendant Button	
<b>S</b>	Arm Swivel	LFT(S+)	RHT(S-)
<b>H</b>	Arm Forward and Backward	BWD(H+)	FWD(H-)
<b>V</b>	Arm Upward and Downward	UP(V+)	DOWN(V-)
<b>R2</b>	Wrist Rotation 2	Rx+(R2+)	Rx-(R2-)
<b>B</b>	Wrist Bend	Ry+(B+)	Ry-(B-)
<b>R1</b>	Wrist Rotation 1	Rz+(R1+)	Rz-(R1-)




Figure 2.5 Robot Dimension and Axis [HR050/HR030L]

### 2.6. Details of Wrist Axis Attachment Surface

When attaching the operating tool to the mechanical interface of robot's wrist flange, fasten it with a bolt at P.C.D. 100.




Figure 2.6 Details of Wrist Axis Attachment Surface : [HR050/HR030L]

**HYUNDAI**  
HEAVY INDUSTRIES CO.,LTD.

## 2.7. Details of Upper 1st ARM Attachment Surface

The upper parts of the arm frame and arm pipe of the robots are attached using a tap designed to attach peripheral devices. Within the area marked with ▦, peripheral devices (valves, etc.) shall be attached.

### [Attention]

- Max weight on the A1 Frame : 20kg




Figure 2.7 Details of Upper 1st ARM Attachment Surface



### 2.8. Application Wiring and Inspection Wiring Diagram

There are air unit and connector to connect the additional equipment to the robot manipulator. Application connectors are indicated as follows.

[Note] Max air pressure of air connection : 5.0bar (5.1 kgf/cm<sup>2</sup>, 72.5 psi)




Figure 2.8 Application Wiring and Inspection Wiring Diagram : [H050/HR030L]

### 2.8.1. Details of Customer Application Connectors



	<p>&lt;ASR 1&gt;</p> <ul style="list-style-type: none"> <li>• Cable : 2*0.2 sq * 5p</li> <li>• Connector type : HAN 24 DD (M)</li> <li>• Mating connector type : HAN 24 DD (F)</li> </ul>	<p>&lt;ASR 1A&gt;</p> <ul style="list-style-type: none"> <li>• Cable : 2*0.2 sq * 5p</li> <li>• Connector type : HAN 24 DD (F)</li> <li>• Mating connector type : HAN 24 DD (M)</li> </ul>
	<p>&lt;ASR 2&gt;</p> <ul style="list-style-type: none"> <li>• Cable : 1.0 sq * 7 c</li> <li>• Connector type : HAN 8D (M)</li> <li>• Mating connector type : HAN 8D (F)</li> </ul>	<p>&lt;ASR 2A&gt;</p> <ul style="list-style-type: none"> <li>• Cable : 1.0 sq * 7 c</li> <li>• Connector type : HAN 8D (F)</li> <li>• Mating connector type : HAN 8D (M)</li> </ul>

Figure 2.9 Details of Application Connector : [HR050/HR030L]

### 2.9. Restricting the Working Envelope

When installing the robot, take into account that the working envelope can be adjusted freely within the entire working envelope.

Limiting the motion range is useful when:

- During robot operation
- When the robot is likely to collide with another device
- When the length of the application cables or hose pipes are limited

There are three methods to use to limit the motion range of the robot as follows:

- Software limit (applied to the entire axis)
- Limit switch (1-3 axis: optional application)
- Mechanical stopper (1-3 axes)



#### [Warning]

The mechanical stopper is a physical device. The robot should not exceed the area occupied by the mechanical stopper. The mechanical stopper of a 1-3 axis is fixed. The mechanical stopper with a 4-6 axis is applied only within the software limits.

Once the mechanical stopper is collided with, its strength cannot be guaranteed. Therefore, please ensure it is replaced after impact.

#### 2.9.1. Axis 1(Axis S)

By adding one more mechanical stopper, the working envelope of the 1st axis can be limited. (by 30°). If the 1st STOPPER BLOCK and STOPPER are deformed due to a great impact, they must be replaced.





**HYUNDAI**  
HEAVY INDUSTRIES CO., LTD.

**3**

**Instructions**



## 3. Instructions

HR050/HR030L

### 3.1. Robot Component Name

The following [Figure 3.1] show and name each component of the robot.




Figure 3.1 Name of Robot Components : [HR050/HR030L]

Table 3-1 Components name : [HR050/HR030L]

No.	Component Name	No.	Component Name
1	BASE BODY	8	S axis Motor
2	A2 FRAME	9	H axis Motor
3	2 <sup>nd</sup> ARM	10	V axis Motor
4	LINK	11	R1 axis Motor
5	HINGE	12	B axis Motor
6	1 <sup>st</sup> ARM	13	R2 axis Motor
7	WRIST	14	S axis Limit Switch



### 3.2. Location of Safety Nameplate

Do not remove or replace unnecessarily.




Figure 3.2 Location of Safety Nameplate [HR050/HR030L]



### 3.3. How to Transport

#### 3.3.1. Using Crane




Figure 3.3 How to Transport: Using crane [HR050]




Figure 3.4 How to Transport: Using crane [HR030L]

The following lifting instructions are valid for a "naked" robot. If additional equipment is put on the robot, the center of gravity may change and make lifting dangerous.



- Never walk under the robot.
- Pose the robot as shown in the Figure.
- Mount four pieces of eye bolt to the base body.
- Connect a wire rope to the eye bolts.
- Use 4 piece of protective hose(four parts/ 50cm) to prevent damage.
- Keep the safety regulations during Lifting process.
- Weight of manipulator : 670kg(HR050/HR030L)
- Minimum crane capacity: 1 tons(HR050/HR030L)



※ Use wire rope in its length of 1.5m(2EA) and 2.5m(2EA). Insert a protective hose to prevent damage of painting at the parts contacted with robot body. Refer to Figures for the proper location of protective hose.

### 3.3.2. Forklift use

A forklift can be used to carry the main body of the robot. The bracket for the forklift transporting, as an option, is provided.

For safety reasons, please pay attention to the following procedures:

- With reference to the pictures provided, use the standard position of each model.
- Before forking, fasten each bracket(2) for forklift to the left and right side of A2 Frame with 4 pieces of M12 bolts and flat washer.
- Carry at a slow speed.
- Follow all safety regulations.



#### Cautions.

- Do not lean against the robot while carrying it.
- Make sure the robot does not collide with the floor while loading and unloading.
- Pay attention to the relevant safety rules while using the forklift truck.




Figure 3.5 How to Transport : Using forklift [HR050]




Figure 3.6 How to Transport : Using forklift [HR030L]

### 3.4. How to Install



**NOTE:**

Before starting to unpack and install the robot, read the safety regulations and other instructions very carefully..



**Warning:**

The installation shall be made by qualified installation personnel and should conform to all national and local codes.

When unpacking the robot, check if it has been damaged during transporting or unpacking. In addition, strictly keep the following installation instructions because installation method and foundation are very important to maintain a good robot performance.

#### 3.4.1. Operating Conditions

- (1) Ambient temperature should range from 0°C to 45°C.
- (2) Ambient humidity should range from 20% to 85% RH, without dew condensation.
- (3) Less dust, oil, or moisture.
- (4) No flammable, corrosive liquid or GAS.
- (5) No impact and shacking.
- (6) No electrical noise generator near the robot.
- (7) If the robot is not immediately installed, keep it in a dry area at an ambient temperature between -15°C ~ and 40°C.

#### 3.4.2. Installation the Robot Manipulator

The base floor to install the robot should be constructed with concrete with a thickness of 300mm or more so that the hardness minimizes dynamic effect to the robot. Repair bumps and cracks on the concrete surface of the floor during installation, and fix the mounting place with M20 Chemical Anchor. And if the thickness of the concrete floor is less than 300mm, it requires an independent base construction that must be reviewed beforehand.

Locate the robot unit on the mounting plate and tightly assemble 8 M20 bolts.

- Bolts : M20\*65 of higher(12.9) SOCKET HEAD BOLT
- Washer : OD = 44mm, ID = 25mm, T = 4mm
- Tightening Torque: 314Nm

The stiffness of the foundation must be designed to minimize the influence of the dynamic behavior of the robot.

In case of installing the robot on the floor, where the concrete thickness is more than 200mm, remove unevenness and cracks on the floor, and then fix the mounting plate with M20 Anchor Bolts. If the thickness of concrete is less than 200mm, the foundation work is required. Thus, inspect the foundation before robot installation.

※ Allowable load of bolts

The repeated tensile load per bolt : Approximately 8,820 N ( 900 Kgf )

### 3.4.3. Accuracy of Installation Surface

The degree of flatness for the four attachment plate surfaces should satisfy the specification. Use a shim, if necessary. The rest of the surface must be flat within  $\pm 2\text{mm}$ .

■ Cautions

- (1) The flatness of mounting plate must be within 1.0 mm.
- (2) Make four plane figures of a sealed plate of 1.0 mm ( $\pm 0.5\text{ mm}$ ) or less.




Figure 3.7 Accuracy of Installation surface



#### 3.4.4. Dimension of Installation Surface

Fix the swivel base for robot's installation.  
Refer to [Figure 3.8] for the dimension.




Figure 3.8 Dimension of Robot Installation : [HR050/HR030L]

### 3.5. Allowable Load of Wrist Axis

#### 3.5.1. Permitted load torque estimation

The load, which will be applied to the mechanical interface of robot's wrist axis, is restricted by allowable weight, allowable load torque and allowable moment of inertia.



#### Allowable Maximum Pay Load Weight :

Table 3-2 Allowable load weight

Robot Model	Allowable Load Weight
HR050	Less than 490.5 N (50kgf)
HR030L	Less than 294.3 N (30kgf)



#### Allowable Load Torque

Table 3-3 Allowable Load Torque

Robot Model	Allowable Load Torque		
	R2 Axis Rotation	B Axis Rotation	R1 Axis Rotation
HR050	Less than 176.5 N·m (18 kgf·m)		Less than 88.3 N·m (9 kgf·m)
HR030L	Less than 117.6 N·m (12 kgf·m)		Less than 58.8 N·m (6 kgf·m)



#### Allowable Moment of Inertia

Table 3-4 Allowable Load Torque

Robot Model	Allowable Moment of Inertia		
	R2 Axis Rotation	B Axis Rotation	R1 Axis Rotation
HR050	6.48kg·m <sup>2</sup> (0.66kgf·m·s <sup>2</sup> )		1.62kg·m <sup>2</sup> (0.17kgf·m·s <sup>2</sup> )
HR030L	4.80kg·m <sup>2</sup> (0.49kgf·m·s <sup>2</sup> )		1.20kg·m <sup>2</sup> (0.12kgf·m·s <sup>2</sup> )

Loads must be kept below maximum conditions shown in [Table. 3-2 ~ 3-4].



[Fig 3.9 ~ Fig 3.10] show the possible range in which a point load can be positioned, assuming the attached load is a particle. However, as the actual load(End Effector) is not a particle, calculate and evaluate the moment of inertia on each axis. The following example shows moment of inertia calculation assuming the attached load is a particle.

**[Example] An attached load weight is 40Kg with the 【 HR050 】 Model**

- Allowable position of the center of gravity from the center of R1 axis
  - ① Allowable position of the center of gravity from the center of Axis R1  
 $LR1 \leq (\text{Allowable Torque}) / (\text{Load Weight})$   
 $LR1 = 88.3 \text{ N}\cdot\text{m} / (40\text{Kg} \times 9.8 \text{ m/s}^2) = 0.225 \text{ m}$
  - ② Allowable position of the center of gravity from the allowable moment of inertia  
 $LR1 \leq (\text{Allowable moment of inertia} / \text{Load Weight})^{1/2}$   
 $= (1.62 \text{ kg}\cdot\text{m}^2 / 40 \text{ kg})^{1/2} = 0.201 \text{ m} (< 0.225 \text{ m})$

From the above result, the maximum distance from the center of R1 axis becomes 0.201 m, being restricted by the allowable moment of inertia.

- Allowable position of the center of gravity from the center of Axis B  
(The center of B axis is on the same axis of this robot, and the value of the allowable load torque and allowable moment of inertia of B and R2 axes are the same. Therefore, if the allowable condition on the B axis is satisfied, it guarantees to satisfy that on the R2 axis..)
  - ① Allowable position of the center of gravity from the allowable torque  
 $LB \leq (\text{Allowable Torque}) / (\text{Load Weight})$   
 $LB = 176.5 \text{ N}\cdot\text{m} / (40\text{Kg} \times 9.8 \text{ m/s}^2) = 0.450 \text{ m}$
  - ② Allowable position of the center of gravity from the allowable moment of inertia  
 $LB \leq (\text{Allowable moment of inertia} / \text{Load Weight})^{1/2}$   
 $= (6.48 \text{ kg}\cdot\text{m}^2 / 40 \text{ kg})^{1/2} = 0.402 \text{ m} (< 0.450 \text{ m})$

From above result, the maximum distance from the center of B axis becomes 0.402 m, being restricted by the allowable moment of inertia.

■ Torque Map




Figure 3.9 Wrist Axis Torque Mapping:[HR050]




Figure 3.10 Wrist Axis Torque Mapping:[HR030L]

#### 3.6. Recommended Standby Posture

Selecting a good standby posture can save energy and reduce motor temperature.

If the tool is positioned as the figure below, the load on H and V-axes may be minimized.  
In case that the posture shown below might not be attained due to the limited space and time caused by peripheral equipment or cycle times, then contact our company.




Figure 3.11 Recommended Standby Posture





**HYUNDAI**  
HEAVY INDUSTRIES CO., LTD.

4

Inspection



## 4. Inspection

HR050/HR030L

This chapter provides the instructions for regular inspection and overhaul necessary for the prolonged lifetime of robot performance.

### 4.1. Inspection Item and Period

Inspection is positively necessary to continue and maintain the high performance of robot for long-term operation.

There are daily inspection and regular inspection. [Table 4-1] shows basic periods for regular inspections, so inspectors should make an inspection according to the indicated periods.

And overhaul every 35,000 operating hours.

The inspection periods have been reviewed for SPOT Welding. In case of high precision work such as handling, it is recommended to inspect at the half intervals of that period as shown in [Table 4-1].

Table 4-1 Inspection Schedule

Yearly Inspection				Yearly Inspection			
3 months	6 months	9 months	12 months	3 months	6 months	9 months	12 months
3 months	6 months	9 months	1 year	1 year & 3 months	1 year & 6 months	1 year & 9 months	2 years
Daily Inspection							

## 4.2. Inspection Item and Period

Table 4-2 Inspection Items and Periods

Table 1-2 Inspection Items and Intervals

No.	Inspection Intervals			Inspection Items	Inspection method	Standards	Remark
	Daily	3 months	1 year				
Robot Manipulator and Axes common							
1	○			Cleaning	Examine dirt and dust with naked eyes		
2		○		Inspection wiring	Examine any cable damages Examine cable fixing bracket tightening bolts paint marking with naked eyes Examine any cable cover damages with naked eyes		
3		○		Main bolts	Examine paint marking with naked eyes		
4			○	Limit Switch/ Dog	Check the ON-OFF function of limit switch	Check if the emergency stop lamp is on when the limit switch is ON.	
5	○			Motor	Check the abnormal heating Check the abnormal sound		
6			○	Brake	Check the ON/OFF operation of brake release switch Note) Turn the switch off in a second because the ARM of working axis may be dropped when the brake release switch is on	When the brake release switch is OFF, ARM of End Effect will not be dropped.	
Axis S, H, V							
7	○			Reduction gear	Check the abnormal sound Check the shaking(vibrating)		
Axis R2, B, R1							
8		○		Reduction gear	Check the abnormal sound Check the vibrating		
9		○		End Effect tightening bolts	Examine paint marking with naked eyes		
10		○		Diversion	there is any diversion by rotating each axis to the right and reverse direction	should not feel diversion by touch	

- If the robot is utilized in adverse condition(such as spot welding, grinding, etc.), perform the inspection more frequently to ensure proper reliability of the robot system
- Inspect all visible cabling, and replace them if damaged.
- Check the mechanical bumper devices for deformation and damage. If the bumper or Dog is bent, replace it immediately.
- Check the tightening torque of main bolts as shown in [Figure 4.1].
- Check the abnormal noise in an automatic or teaching mode in order to ensure the condition of power transmission(such as motor, reduction gear, etc).





### 4.3. Inspection of Main External Bolts



The recommended bolt torque is shown in [Figure 4.1].

Apply the appropriate torque, where required, using the torque wrench and place the paint marking where the check-up is completed

Table 4-3 Inspection part for main bolts

No.	Inspection parts	No.	Inspection parts
1	S axis motor assembly bolt	9	1 <sup>st</sup> arm joint assembly bolt
2	S axis decelerator assembly bolt	10	For hinge and link fixation
3	H,V axis decelerator assembly bolt	11	For first arm pipe fixation
4	H,V axis motor assembly bolt	12	For wrist fixation
5	R2 axis decelerator assembly bolt	13	For B axis decelerator fixation
6	R2 axis motor assembly bolt	14	For B axis decelerator case fixation
7	R1 axis motor assembly bolt	15	R1 axis decelerator fixation
8	For B axis motor fixation		




Figure 4.1 Inspection Part for Main Bolts [HR050/HR030L]

### 4.4. Inspection of Wrist Backlash

Check a diversion by forcing the end-effector (End Effector : spot gun, hand device, etc.), which is attached to the vertical hem of Wrist, in the direction of back and forth, right and left, and up and down.




Figure 4.2 Abnormal Backlash Inspecting Directions [HR050/HR030L]

## 4.5. Inspection Internal Wiring

Flexible cables are used for internal wiring of robot manipulator. However, when an internal cable is broken or crushed, the robot may malfunction. Therefore, regular inspection is required. When operating in the working envelope according to following inspection conditions, inspection must be completed in advance.

### 4.5.1. The Conditions of Safety Inspection

When performing the operating work such as teaching (except shutting off driving source of industrial robot) in the working envelope, check the following articles before the work. If abnormality is found, correct the problem on the spot and then take necessary actions.

- Check if the covered wire and sheathing are damaged or not.
- Check if the manipulator can be operated or not.
- Check emergency stop function



### 4.5.2. Inspection Part




Figure 4.3 Cable Inspection Parts





**HYUNDAI**  
HEAVY INDUSTRIES

**5**

**Maintenance**



## 5. Maintenance

HR050/HR030L

### 5.1. Grease Replenishment/Replacement



#### Attention

If greasing is performed incorrectly, the internal pressure of the grease bath may suddenly increase, possibly causing damage to the seal, which would in turn lead to grease leakage and abnormal operation. When performing greasing, therefore, observe the following cautions.

- ① Before starting to grease, remove the plug from the grease outlet.
- ② Whenever possible, avoid using a compressed-air pump, powered by the factory air supply. If the use of a compressed-air pump is unavoidable, restrict the greasing pressure less than 7bar(7kgf/cm<sup>2</sup>)
- ③ Use grease only of the specified type. If not, may damage the reduction gear or lead to other problems.
- ④ After greasing, confirm that no grease is leaking from the grease outlet and that the grease bath is not pressurized, then re-attach the plug in the grease outlet.
- ⑤ To prevent accidents caused by slipping, completely remove any excess grease from the floor or robot.
- ⑥ When an ambient temperature is more than 40℃, be sure to shorten the period of replenishment in half.


#### ■ Periodic Replenishment / Replacement

##### Lubrication Cycle

- ✓ Grease Replenishment : 6,000 hours
- ✓ Grease Replacement : 12,000 hours



### 5.1.1. S-Axis Reduction Gear



#### **Attention**

If grease is added without removing the outlet plug, the grease will go inside the motor and may damage it. It is absolutely necessary to remove the plug.

#### ■ Grease Replenishment

- ① Remove the grease outlet plug.
- ② Inject the grease into the grease inlet using a grease gun.

- ✓ Grease type : VIGOGREASE RE0
- ✓ Amount of grease : 500cc



#### **Caution**

If the specification of the currently filled grease is MOLYWHITE RE00, you must fill the VIGO GREASE RE0 grease after more than 100 hours of operation.

- ③ Wipe the outlet port with a cloth and attach the plug with seal tape.

■ Grease Replacement


- ① Remove the grease outlet plug.
- ② Inject the grease into the grease inlet using a grease gun.

✓ Grease type : VIGOGREASE RE0  
✓ Amount of grease : 2,500cc

- ③ The grease replacement is complete when new grease appears in the outlet port. The new grease can be distinguished from the old one by color.
- ④ Wipe the outlet port with a cloth and attach the plug with seal tape.



### 5.1.2. H/V-Axis Reduction Gear



#### **Attention**

If grease is added without removing the outlet plug, it cause damage to the seal of reducer and grease will go inside the motor and may damage it. It is absolutely necessary to remove the plug.

#### ■ Grease Replenishment

- ① Make the H-Axis Arm vertical for ground. (H:90°-Floor Type, H:0°-Shelf Type)
- ② Remove the grease outlet plug.
- ③ Inject the grease into the grease inlet using a grease gun.

- ✓ Grease type : VIGOGREASE RE0
- ✓ Amount of grease : 150cc



#### **Caution**

If the specification of the currently filled grease is MOLYWHITE RE00, you must fill the VIGO GREASE RE0 grease after more than 100 hours of operation.

- ④ Wipe the outlet port with a cloth and attach the plug with seal tape.

■ Grease Replacement


- ① Make the H-Axis arm vertical and the V-Axis arm horizontal for ground.
- ② Remove the grease outlet plug.
- ③ Inject the grease into the grease inlet using a grease gun.

✓ Grease type : VIGOGREASE RE0  
✓ Amount of grease : 760cc

- ④ The grease replacement is complete when new grease appears in the outlet port. The new grease can be distinguished from the old one by color.
- ⑤ Move the H-Axis for a few minutes to eject the old grease and then add grease until the new grease appears in the outlet port.
- ⑥ Wipe the outlet port with a cloth and attach the plug with seal tape.



### 5.1.3. R2-Axis Reduction Gear



#### **Attention**

If grease is added without removing the outlet plug, it cause damage to the seal of reducer and grease will go inside the motor and may damage it. It is absolutely necessary to remove the plug.

#### ■ Grease Replenishment

- ① Remove the grease outlet plug.
- ② Inject the grease into the grease inlet using a grease gun.

- ✓ Grease type : VIGOGREASE RE0
- ✓ Amount of grease : 50cc



#### **Caution**

If the specification of the currently filled grease is MOLYWHITE RE00, you must fill the VIGO GREASE RE0 grease after more than 100 hours of operation.

- ③ Wipe the outlet port with a cloth and attach the plug with seal tape.

■ Grease Replacement


- ① Remove the grease outlet plug.
- ② Inject the grease into the grease inlet using a grease gun.

✓ Grease type : VIGOGREASE RE0  
✓ Amount of grease : 240cc

- ③ The grease replacement is complete when new grease appears in the outlet port. The new grease can be distinguished from the old one by color.
- ④ Wipe the outlet port with a cloth and attach the plug with seal tape.



### 5.1.4. B/R1-Axis Reduction Gear



#### **Attention**

If grease is added without removing the outlet plug, it cause damage to the seal of reducer and grease will go inside the motor and may damage it. It is absolutely necessary to remove the plug.

#### ■ Grease Replenishment

- ① Prepare a grease nipple A-PT1/8 and then make the R2-Axis 0°degree.
- ② Remove the grease inlet plug and install grease nipple A-PT1/8.
- ③ Make the R2-Axis -90°degree and then remove the grease outlet plug.
- ④ Inject the grease into the grease inlet using a grease gun.

- ✓ Grease type : VIGOGREASE RE0
- ✓ Amount of grease : 40cc (B-Axis) / 30CC (R1-Axis)



#### **Caution**

If the specification of the currently filled grease is MOLYWHITE RE00, you must fill the VIGO GREASE RE0 grease after more than 100 hours of operation.

- ⑤ Wipe the outlet port with a cloth and reinstall the inlet/outlet plugs with seal tape

■ Grease Replacement

- ① Prepare a grease nipple A-PT1/8 and then make the R2-Axis 0°degree.
- ② Remove the grease inlet plug and install grease nipple A-PT1/8.
- ③ Make the R2-Axis -90°degree and then remove the grease outlet plug.
- ④ Inject the grease into the grease inlet using a grease gun.


- ✓ **Grease type : VIGOGREASE RE0**
- ✓ **Amount of grease : 180cc (B-Axis) / 140CC (R1-Axis)**

- ⑤ The grease replacement is complete when new grease appears in the outlet port. The new grease can be distinguished from the old one by color.
- ⑥ Wipe the outlet port with a cloth and reinstall the inlet/outlet plug with seal tape.





### 5.1.5. Bearing Joint Parts



#### ■ Grease Replenishment

Inject the grease into the grease inlet using a grease gun.

- ✓ Grease type : Gadus S2 V46 2
- ✓ Amount of grease : 3cc

## 5.2. Battery Replacement

The position data of each axis is preserved by the backup batteries. The batteries need to be replaced every two years. To replace batteries observe the following procedure.

- ① Keep the power on. Press the Emergency Stop button to prohibit the robot motion.



### Attention

Replacing the batteries with the power supply turned off causes all current position data to be lost. Therefore, zeroing will be required again.

- ② Uncover the BJ1 of robot manipulator.
- ③ Take out the old batteries from the battery cover.
- ④ Insert new batteries into it. Pay attention to the direction of batteries.

- ✓ **Battery Spec. : ER6C(AA) 3.6V**
- ✓ **Manufacturer : Maxell**

- ⑤ Reinstall the battery BJ1 cover.




Figure 5.1 Location of Battery Replacement



### **Attention**

- ✓ Do not dispose the batteries. Dispose of the battery with industrial waste according to the laws and other rules in the country where the controller is installed.
- ✓ Do not recharge the batteries, otherwise batteries may result in exploding or overheating.
- ✓ Do not use any batteries other than the recommended one.
- ✓ Change the batteries only with the specified one.
- ✓ Do not short positive and negative terminals of battery.
- ✓ Do not expose batteries to high temperature or flame

### 5.2.1. Instructions for Battery Storage

- (1) Do not keep the batteries at a high temperature and humidity. Keep it in the well-ventilating place without dew condensation.
- (2) Keep it in a normal temperature, at relatively constant temperature ( $20\pm15^{\circ}\text{C}$ ) and at relative humidity of less than 70%.
- (3) Check the battery storage every six months, and manage them with first-in-first-out.



### 5.3. Internal Wiring

Replacement cycle of internal wiring depends on follows.

- Continuous operation
- Operating speed
- Atmosphere/environment


Inspect on a regular basis, every three months and check any damage on the cables or cable protect spring. If any damage, replace it.

Replace the cable every 16,000 operating hours regardless of working condition.



#### **Attention**

- ✓ As all the wires are flexible type, do not use any wires other than specified one.
- ✓ Wiring replacement must be done by unit.
- ✓ Do not use any Cable, protective spring, and Hose that have external damage as they may cause future problems.
- ✓ When purchasing robot cables, make inquiry of our service office about wiring type.
- ✓ Specify the length of wiring for connecting the robot with the controller.



### 5.3.1. Wiring Connection Diagram

Refer to [Fig 5.2] for part symbols of the internal wiring.





Figure 5.2 Explains of internal wiring



**HYUNDAI**  
HEAVY INDUSTRIES GROUP

6

Troubleshooting



## 6. Troubleshooting

HR050/HR030L

### 6.1. Troubleshooting Procedure

If a failure occurs during robot's operation, but it does not stem from the controller, it must be caused by damage on machine parts. The way to troubleshoot as quick and easy as possible should be to diagnose the problem. In addition, it is necessary to determine which parts cause the problem.

- (1) Step 1 : Which axis occurs the problem?  
First of all, check which axis causes the malfunction. In case that it is hard to detect the problem, check the following possible mechanical defaults.
  - Is there any parts making noise?
  - Is there any parts generating an overheating?
  - Is there any parts have a play or backlash?
- (2) Step 2 : Which parts have been damaged?  
If the abnormal axes are determined, investigate which parts cause trouble. There could be many causes for one phenomenon. Refer to [Table 6-1] for the cause and phenomenon of the trouble.
- (3) Step 3 : Dealing with malfunction parts  
If the malfunction parts are confirmed, conduct relevant repair procedure based on the chapter 『6.3 Diagnostics and Resolutions for Major Parts Failure』. Contact our service office if you have any difficulties in dealing with problems.





## 6.2. Trouble Symptoms and Possible Causes

As shown in [table 6-1], there may be many parts as the cause of one phenomenon.  
Refer to next page to determine which part is malfunction.

Table 6-1 Trouble phenomenon and cause

Defect parts Trouble phenomenon	Reduction gear	Brake	Motor	Encoder	Backlash	Fulcrum bearing
Overload [Note 1]	○	○	○			
Displacement	○		○	○		
Abnormal sound occurrence	○	○	○			○
Noise in operation [Note 2]			○		○	
Staggering at stop [Note 3]			○	○		
Irregular twitching [Note 4]			○	○		
Abnormal deviation			○	○		
Free fall of an axis	○	○				
Overheating	○	○	○	○		○
Incorrect action and out of control movement			○	○		

[Note 1] Overload ----- Phenomenon occurring when a load exceeds the rated motor load.  
In specific, thermal relay of circuit protector is tripped.

[Note 2] Noise in operation ----- Phenomenon which occurs vibration on operation.

[Note 3] Staggering at stop ----- Phenomenon which gives oscillating motion when the robot stops.

[Note 4] Irregular twitching ----- Phenomenon which gives sporadic twitching when the robot is not in motion.

## 6.3. Diagnostics and Resolutions for Major Parts Failure

### 6.3.1. Fulcrum Bearings

Vibration, abnormal sound and overloads are observed when a fulcrum bearing is damaged. When the Nut holding bearings becomes loose, bearing play occurs. It may damage the bearings.

■ **Diagnostics**

- ① Shake the 1<sup>st</sup> ARM and 2<sup>nd</sup> ARM back and forth to check if bearing exhibits any play. (In case of using a chain block, check the bearings for the play, with the 1<sup>st</sup> ARM and 2<sup>nd</sup> ARM posture maintaining and without any overload to the reduction gear.
- ② Check to see if the robot touched other peripheral equipment before the malfunction.

■ **Resolution**

Replace the bearing. A Chain Block is needed to lift and hang the robot ARM. Contact our service office for any difficulties..



### 6.3.2. Reduction Gear

Vibration and abnormal sound will be occurred when a reduction gear is damaged. In this case, it causes overload and abnormal deviation disturbing normal operation. Sometimes overheating may result. The robot may also become completely immovable, or a position offset error may occur.



#### [Main Axes (S, H, V)]

When turning [ON][OFF] the brake release switch of axis H and axis V, be sure to take necessary precautions to prevent the ARM from dropping, and then switch the brake release [ON][OFF]..

#### ■ Diagnostics

- ① Check out any vibration, abnormal sound or overheating of the reduction gear when the robot is in operation.
- ② Check out any play and abrasion in the reduction gear. And check if any abnormality is felt by hand when shaking 1<sup>st</sup> ARM back and forth with the brake release switch of axis S [ON].
- ③ Check if peripheral equipment has been contacted with the robot before the abnormality. (Damage may occur to the reduction gear due to the contacting impact.)

#### ■ Resolution

Replace the reduction gear. A chain block is needed to lift and hang the robot ARM. Contact our service office for any difficulties.



#### [Wrist Axes (R2, B, R1)]

When turning [ON][OFF] the brake release switch, be sure to take necessary precautions to prevent the ARM from dropping, and then switch the brake release [ON][OFF].

#### ■ Diagnostics

- ① Check out any vibration, abnormal sound, or overheating of the reduction gear when the robot is in operation.
- ② Check out any play in the reduction gear by shaking the End Effector (such as spot gun and hand devices, etc.) back and forth.
- ③ Turn motors off, with the brake release switch [ON], and check that the axis can be rotated by hand. If not, the reduction gear is in bad condition.
- ④ Check if peripheral equipment has been contacted with the robot before the abnormality. (Damage may occur to the reduction gear due to the contacting impact )

#### ■ Resolution

- ① Replace the reduction gear.
- ② Replace the entire wrist section.  
(The replacement of entire wrist should be a quick and reliable resolution as it takes time and necessary equipment for reduction gear replacement)

### 6.3.3. Brakes

In case of brakes failure, each axis possibly drops with the motors [OFF]. Or, in reverse, brakes possibly operate even with the motors [ON]. The latter causes overload and noise.

When intending to operate the entire robot without the motors [ON], operate it with the brake release switch [ON]. Before turning the switch [ON], take necessary precautions to prevent the ARM from dropping as the robot ARM will drop by gravity.

#### ■ Diagnostics

Check if the brake can be heard in operation, by turning the brake release switch [ON] [OFF] alternately with the motors[OFF]. If not heard, the brake cable may be broken. (When operating the brake release switch [ON][OFF], be careful of ARM dropping. The brake release switch is located on the panel in the controller cabinet door.)

#### ■ Resolution

If cables turn out to be good condition, replace the motor.

### 6.3.4. Motor

Motor failure causes abnormal operation of robot such as staggering at stop, irregular twitching and noise in operation. Besides, It may cause overheating and abnormal sound.

Check the reduction gear and fulcrum bearing as well in order to determine which part causes the abnormality. It is because that similar phenomenon is observed when the reduction gear is damaged.

#### ■ Diagnostics

Check for overheating and abnormal sound. .

#### ■ Resolution

Replace the motor.

### 6.3.5. Encoder

Position offset, malfunction, and out of control movement as well as staggering at stop, irregular twitching may occur when the Encoder is in bad condition. This case has nothing to do with such phenomena as mechanical abnormal sound, overheating, and vibration

#### ■ Diagnostics

- ① Check for any encoder data failure.
- ② Use reference pins and blocks to check the positional data is correct at pin position.
- ③ Check for any irregular variations in the encoder data when moving each robot axis.
- ④ Replace the servo amp board, BD542 to check errors.

#### ■ Resolution

- ① If cabling turns out to be in good condition without any damage, replace the encoder.
- ② If there is no error after replacing the servo amp board BD542, replace the servo amp board.



## 6.4. Motor Replacement



### Warning:

When motor is separated, the ARM will drop due to its built-in brakes inside the motor for holding robot's posture. To prevent this drop, please make sure safety measures, such as suspending the arm with devices like a crane, etc., or fixing the 1<sup>st</sup> arm and the 2<sup>nd</sup> arm with fixing pins, are employed.

In case of contacting the motor right after it stops, ensure the motor temperature. Motor weights are listed as follows. Be careful when dealing with the motor.



### Warning:

In this work, there is a part performed with the motor [ON]. Therefore, perform the work in pairs. An observer must always be ready to activate an emergency stop. The other perform the work quickly and carefully. An escape route should be determined before starting work.



### 6.4.1. Necessary Tools and Parts

Table 6-2 Necessary Tools

Tool Name	Part No.(Model)	Remark
<b>Torque wrench ( prepared by user)</b>	M8 Torque wrench (Lock type) M6 Torque wrench (Lock type) M5 Torque wrench (Lock type) M4 Torque wrench (Lock type)	Use torque wrench and extension on the market

Table 6-3 Necessary parts and zero point setting method by axis

Model	Necessary parts	S	H	V	R2	B	R1
<b>HR050 /030L</b>	Location setting block						○
	Block connection bolt						○
	Bolt size						M8 × 20(2EA) PPI8 × 20(2EA)

(When overhauling the robot, a leveling bulb can be used to focus on the precise starting point. To focus on the precise starting point, please contact us.)

### 6.4.2. How to Replace Motor

- (1) Put the controller into TEACH mode and select motors [ON]. When the motors [On] state cannot be obtained, check the respective ARM is firmly fixed while supporting it to prevent dropping. And then begin at step No.4.
- (2) The axis requiring motor replacement takes basic posture.
- (3) In case of main axes(S, H, V) : Refer to [Figure 6.1].  
Set the origin by using SCALES. [HR050/HR030L]  
In case of wrist axes (R2, B, R1) : Set the origin by using SCALES.
- (4) Turn the main power [OFF] with the controller power [OFF].
- (5) Disconnect the connector from the motor.
- (6) Remove attachment bolts of motor and pull the motor out of robot. When removing motors of axis H or V, be sure not to damage the lip of oil seal due to the gear attached to the axis of motor.
- (7) Detach the gear from the motor shaft. not give excessive impact to the motor shaft.
- (8) Assemble the gear after lightly applying grease to the shaft.  
The bolt used to attach the gear to the shaft should be cleaned and removed of grease before using. Apply loctite 243 to the screw part of the bolt, and then tighten it using a torque wrench in a regular torque. , Besides, slowly tighten the bolt in a symmetrical order.
- (9) Assemble the motor on the robot after applying a small amount of grease to the lip of oil seal and applying a moderate amount of grease to the teeth of gear. When assembly the main axis motor, be sure not to damage the lip of oil seal.
- (10) Connect the connector to the motor.
- (11) When replacing the axis H or V, replenish the grease as the amount as it lost.
- (12) Reset the encoder of the axis whose motor is replaced.



#### Warning

Before encoder correction, check motor connections, with motors [ON], while pressing the Enable switch for 2~3 seconds.

- (13) Perform the encoder calibration about the axis whose motor is replaced. Refer to the chapter [Encoder Calibration] in the controller operating manual..
- (14) Remove M20 bolt, a supporting bolt for preventing possible dropping of axis H /V.
- (15) Confirm that there is no error in robot's motion.



### 6.5. Encoder Zero Setting

It is necessary to reset the origin when encoder data has been corrupted due to some problems and when the motor is replaced.

Level and Block is adopted as the position setting method for each axis. The origin must be set in order of axis 4, 5, and 6 considering axis interference of the wrist due to its structural characteristic.



#### **Warning**

In this work, there is a part performing in the state of motor [ON]. Therefore, this work must be performed in pairs. One must always be ready to activate an emergency stop. The other must perform the work quickly but carefully.

An escape route should be determined before starting work.



### 6.5.1. Zero Setting

- (1) Put the controller into TEACH mode and select [MOTOR ON]. If you cannot select MOTOR On due to abnormality, set the origin position of the robot by using the brake release switch.
- (2) Move respective axes to the basic posture, then set them by the scale mark.
- (3) Reset the Encoder. Refer to 『6.5.2 Encoder Reset』 for the method of encoder reset.
- (4) Correct the encoder. Refer to 『Controller Operation Manual』 .
- (5) Confirm that there is no problem in robot motion.





Figure 6.1 Method of Zero Setting [HR050/HR030L]

### 6.5.2. Encoder Reset

- (1) Turn off the motor.
- (2) Open the serial encoder reset window. ( 『F2]: System』 → 『5: Initialize』 → 『4: Serial encoder reset』 )



- (3) Use keys like [↓], [↑], [SHIFT]+[←][→] to move to a desirable axis, then press the [Execute] key.
- (4) After the encoder is reset, please make sure the controller power is turned on.

### 6.5.3. Encoder offset and Selection

- It is necessary to compensate encoder data for the basic position of each axis.
- Refer to 『Encoder offset』 in the Controller Manual for details.

#### [Encoder offset Screen]

	Adjust[%s]	Current[%s]	Angle[deg]
S	FFC00A28 [hex]	003FF5DD [hex]	0.708 [deg]
H	FFC00803 [hex]	003FF7FD [hex]	91.230 [deg]
V	FFC01223 [hex]	003FEDDD [hex]	1.452 [deg]
R2	FFC00020 [hex]	003FFFE0 [hex]	0.225 [deg]
B	FFC0054B [hex]	003FFAB5 [hex]	-90.740 [deg]
R1	FFC01EFE [hex]	003FE102 [hex]	3.487 [deg]
T1	0008843A [hex]	FFF77BC6 [hex]	-1886.396 [mm]
T2	FF8F1683 [hex]	0090E97D [hex]	-2104.792 [mm]
T3	FFC002FA [hex]	003FFD06 [hex]	-0.116 [deg]
T4	FFC00EBT [hex]	003FF14F [hex]	-0.660 [deg]

After moving the selected axis with the jog key, press the [Apply] key.

Apply Apply all Complete PREVIOUS

- (1) Select the axis, move the axis to a standard position using the [Axis operation] key, and press the 『[F1]: Apply』 key.
- (2) Place the robot's entire axis as the standard position using the [Axis operation] key and press the 『[F2]: Apply all』 key to carry out encoder offset correction for the entire axis.
- (3) To save the set data, press the 『[F7]: Complete』 key. The [ESC] key will prevent the changes being saved.



#### Warning

In case of encoder DATA compensation after replacing motor, check if the motor power is on with the power 『ON』.



**HYUNDAI**  
HEAVY INDUSTRIES CORPORATION

7

**Recommended  
Spare Parts**



## 7. Recommended Spare Parts

HR050/HR030L

The recommended spare parts for robot are as follows. Please check robot serial number and manufacturing date when purchasing, and contact our service office.

[Category]

A : Regular maintenance parts(what is replaced regularly)

B : Essential spare parts (what is of high frequency)

C : Essential component parts

D : Machine parts

Table 7-1 Spare Parts List I

Category	Part Name	Manufacturer	Per Unit		Application
		Specification	Use	Rec.	
A	Grease	HHI		16kg /CAN	RV reduction gear
		VIGOGREASE RE0			
A	Grease	HHI		16kg /CAN	Gears and bearing on each axes
		Gadus S2 V46 2			
A	Encoder battery	HHI	6EA	6EA	Regardless of operation time, change it in 2 years
		Base			
A	Timing belt	HHI	1EA	1EA	R2 axis(A1-94)
		R13-203094-00 (632-8YU-20)			
A	Timing belt	HHI	1EA	1EA	B axis(A1-95)
		R13-203095-00 (544-8YU-20)			
A	Timing belt	HHI	1EA	1EA	R1 axis(W1-92)
		R13-204093-00 (320-5GT-12)			
B	AC Servo motor	HHI	3EA	1EA	S, H, V axis
		R13-201051-00 (TSM1319 N8235 E232)			
B	AC servo motor	HHI	3EA	1EA	R2, B, R1 axis
		R13-203051-00 (TSM1303 N8221 E230)			

## 7. Recommended Spare Parts

Category	Part Name	Manufacturer	Per Unit		Application
		Specification	Use	Rec.	
C	Wrist ass'y	HHI	1EA	1EA	
		R13-200010-00			
C	RV reduction gear	HHI	1EA	1EA	S axis
		R13-201052-00 (51L006-30)			
C	RV reduction gear	HHI	2EA	1EA	H, V axis
		R13-202052-00 (55E028E10)			
C	RV reduction gear	HHI	1EA	1EA	R2 axis
		R13-203052-00 (35E024J10)			
C	RV reduction gear	HHI	1EA	1EA	B axis
		R13-205100B-00 (30K060-10)			
C	RV reduction gear	HHI	1EA	1EA	R1 axis
		R13-204051-00 (20K038-10)			
C	BJ1 wiring ASS'Y	HHI	1EA	1EA	
		R13-205100A-00			
C	BJ2 wiring ASS'Y	HHI	1EA		
		R13-205100B-00			
D	Cross roller bearing	HHI	1EA	1EA	Support center shaft in A2
		R13-202061-00 (RB20025UU)			
D	Taper roller bearing	HHI	4EA	4EA	A2 part V axis Link Upper & Lower Joint
		R13-202062-00 (32005XJ)			

Category	Part Name	Manufacturer	Per Unit		Application
		Specification	Use	Rec.	
D	Taper roller bearing	HHI	2EA	2EA	Joint lower and upper Link of axis V in A2
		R13-202063-00 (32012XJ)			
D	Oil seal	HHI	1EA	1EA	Center gear of S axis reduction gear
		R13-201085-00			
D	Oil seal	HHI	1EA	1EA	Motor Base in S axis
		R13-201086-00			
D	Oil seal	HHI	2EA	1EA	Motor Base in H, V axis
		R13-202082-00			
D	Oil seal	HHI	1EA	1EA	Input gear of R2 axis
		R13-203081-00			
D	Oil seal	HHI	1EA	1EA	Shaft of B axis (A1 pipe)
		R13-203082-00			
D	Oil seal	HHI	1EA	1EA	Shaft of B axis (A1 pipe)
		R13-203083-00			
D	Oil seal	HHI	2EA	1EA	Belt shaft of R1 axis
		R13-204081-00			
D	V ring	HHI	2EA	1EA	Upper shaft of upper ARM in A2
		R13-202085-00			
D	O ring	HHI	1EA	1EA	Reduction gear shaft and assemble surface of S1 base body
		R13-201081-00			



## 7. Recommended Spare Parts

Category	Part Name	Manufacturer	Per Unit		Application
		Specification	Use	Rec.	
D	O ring	HHI	1EA	1EA	Reduction gear shaft and assemble surface of S1 base body
		R13-201082-00			
D	O ring	HHI	1EA	1EA	Reduction gear shaft and assemble surface of S1 center shaft
		R13-201083-00			
D	O ring	HHI	1EA	1EA	Case of reduction gear and assemble surface of A2 frame
		R13-201084-00			
D	O ring	HHI	2EA	2EA	Case of reduction gear and assemble surface of A2 motor base
		R13-201081-00			
D	O ring	HHI	1EA	1EA	Case of reduction gear and assemble surface of A1 frame
		R13-203084-00			
D	O ring	HHI	1EA	1EA	Output outlet of reduction gear and assemble surface of A1 flange
		R13-203085-00			
D	O ring	HHI	6EA	6EA	Output outlet of reduction gear and assemble surface of A1 flange
		R13-203086-00			
D	O ring	HHI	1EA	1EA	A1 pipe and assemble surface of A1 flange
		R13-203087-00			
D	O ring	HHI	2EA	2EA	Wrist holder and assemble surface of bearing case
		R13-204082-00			
D	O ring	HHI	1EA	1EA	Wrist holder and assemble surface of bearing case
		R13-204083-00			

Category	Part Name	Manufacturer	Per Unit		Application
		Specification	Use	Rec.	
D	O ring	HHI	1EA	1EA	Case of reduction gear in R1 and assemble surface of wrist holder
		R13-204084-00			
D	O ring	HHI	1EA	1EA	Output outlet of reduction gear in B1 and assemble surface of wrist holder
		R13-204085-00			
D	O ring	HHI	1EA	1EA	Case of reduction gear in B1 and assemble surface of wrist body
		R13-204086-00			
D	O ring	HHI	1EA	1EA	Wrist body and assemble surface of A1 pipe
		R13-204087-00			
D	O ring	HHI	1EA	1EA	Wrist body and assemble surface of bearing case
		R13-204088-00			



**HYUNDAI**  
HEAVY INDUSTRIES CORP.

8

Internal Wiring  
Diagram



## 8. Internal Wiring Diagram

HR050/HR030L

Internal wiring is shown in a connection diagram per unit, and thus utilize it to inspect and replace the wiring.

### 8.1. Manipulator Configuration




Figure 8.1 Manipulator Configuration

## 8.2. Wiring Diagram




Figure 8.2 Cabling diagram [HR050/HR030L]




Figure 8.3 Motor Power Cable [HR050/HR030L]

## 8. Internal Wiring Diagram




Figure 8.4 Axis S & H, Encoder Wiring Connection [HR050/HR030L]





Figure 8.5 Axis V & R2, Encoder Wiring Connection [HR050/HR030L]













**HYUNDAI**  
HEAVY INDUSTRIES CORP.

9

Decommissioning



## 9. Decommissioning

HR050/HR030L

### 9.1. Material for each robot part

The robot is made up of several materials as shown in [Table 9-1]. Some of them should be properly arranged and sealed up to eliminate any bad influence on the human body or environment.

Table 9-1 Materials of each part

Parts	Materials
Battery	NiCad or Lithium
Wiring, Motor	Copper
Base body, A2 Frame, Upper Frame, Hinge etc.	Cast Iron
A1 pipe	Steel
Brakes, Motors	Samarium Cobalt(or Neodymium)
Wiring, Connectors	Plastic / Rubber
Reduction gears, Bearings	Oil / Grease
A1 frame, Wrist pipe,[HR050/HR030L] R1 axis motor base etc..	Aluminum alloy cast



- **Head Office**

Tel. 82-52-202-7901 / Fax. 82-52-202-7900  
1, Jeonha-dong, Dong-gu, Ulsan, Korea

- **A/S Center**

Tel. 82-52-202-5041 / Fax. 82-52-202-7960

- **Seoul Office**

Tel. 82-2-746-4711 / Fax. 82-2-746-4720  
140-2, Gye-dong, Jongno-gu, Seoul, Korea

- **Ansan Office**

Tel. 82-31-409-4945 / Fax. 82-31-409-4946  
1431-2, Sa-dong, Sangnok-gu, Ansan-si, Gyeonggi-do, Korea

- **Cheonan Office**

Tel. 82-41-576-4294 / Fax. 82-41-576-4296  
355-15, Daga-dong, Cheonan-si, Chungcheongnam-do, Korea

- **Daegu Office**

Tel. 82-53-746-6232 / Fax. 82-53-746-6231  
223-5, Beomeo 2-dong, Suseong-gu, Daegu, Korea

- **Gwangju Office**

Tel. 82-62-363-5272 / Fax. 82-62-363-5273  
415-2, Nongseong-dong, Seo-gu, Gwangju, Korea

- **본사**

Tel. 052-202-7901 / Fax. 052-202-7900  
울산광역시 동구 전하동 1 번지

- **A/S 센터**

Tel. 82-52-202-5041 / Fax. 82-52-202-7960

- **서울 사무소**

Tel. 02-746-4711 / Fax. 02-746-4720  
서울특별시 종로구 계동 140-2 번지

- **안산 사무소**

Tel. 031-409-4959 / Fax. 031-409-4946  
경기도 안산시 상록구 사동 1431-2 번지

- **천안 사무소**

Tel. 041-576-4294 / Fax. 041-576-4296  
충남 천안시 다가동 355-15 번지

- **대구 사무소**

Tel. 053-746-6232 / Fax. 053-746-6231  
대구광역시 수성구 범어 2 동 223-5 번지

- **광주 사무소**

Tel. 062-363-5272 / Fax. 062-363-5273  
광주광역시 서구 농성동 415-2 번지