
## WESTGATE


### **LED Troffer Retrofit Kit Installation Instruction**

#### IMPORTANT: Read carefully before installation and retain for future reference.


- RISK OF ELECTRICAL SHOCK. TURN MAIN SWITCH AND CIRCUIT BREAKER TO "**OFF**" POSITION BEFORE SERVICE OR RELAMPING.
- All electrical connections must be in accordance with local codes, ordinances and National Electrical Code. If you are unfamiliar with proper electrical wiring or connections, secure the services of a qualified licensed electrician.
- Proper grounding of the fixture is essential for protection from shock, correct operation of the electronic driver and the elimination of electrical interference.

#### **ITEMS PROVIDED**






#### Accessories package




#### WIRING DIAGRAM

Input: 120V-277V 50Hz/60Hz

Non dimming wiring diagram:



#### Dimming wiring diagram:




\*Remarks: 1pcs for non-dimmable fixture, 3pcs for dimmable fixture.

### **MOUNTING INSTALATION**

WARNING: To prevent the risk of falling, use provided self-tap screws to install safety cable onto the existing fluorescent fixture body.

- Remove existing door, ballast cover, fluorescent tubes and ballast. (Refer to Figure 1A)
   \*NOTE\* This Retrofit should not be used outdoors under any circumstances. Do not install insulation within 3" of any part of
   the luminaire.
- 2. Insert mounting strips between T-Bar and fixture. (Refer to figure 2A)
- 3. Secure the retrofit to mounting strips using the slots and hinge mechanism installed on retrofit. (Refer to Figure 3A)
- 4. Use lanyards on retrofit and screws provided secure to existing troffer. (Refer to Figure 3A)
- Connect the supply wires to driver wires as "Black to Black, "White to White" and "Green to Green" (Refer to Wiring Diagram)
  \*NOTE\* Wiring connections must be made through a provided knock out and should not be altered in any way to avoid electric shock & fire hazard.
- 6. Close the retrofit by using the latches, making sure the latch is fully closed.
- 7. The fixture is now retrofitted and ready

# WESTGATE



\*NOTE\* IF LUMINAIRE IS ALTERED IN ANY WAY DURING INSTALLATION OR PHYSICAL DAMAGE OCCURS WARRANTY WILL VOID.