

## **Operating Instructions**





## Contents

1.	Safety instructions	.2
	Scope of supply	
3.	Operating instructions	.3
4.	Cleaning and service	.5
	General information	
6.	Illustration and components	.6
7.	Spare parts	.7
	Technical information	

## 1. Safety Instructions

- · Check the device for transport damages upon receipt
- Observe the operating instructions and always keep it next to the equipment
- It must be excluded that unauthorised persons operate the equipment
- Secure the dispensing equipment during the cleaning against use
- Do only use with water cocks not connected to a lowpressure flow heater
- We do not accept any liability for damages caused by use of not original parts and accessories, or due to inappropriate handling

# 2. Scope of Supply

- Bevi Handy
- Intake hose
- Drain hose
- Cellar connecting piece
- Connecting piece dispenser tab (2 pieces)
- Cleaning brush
- Cleaning sponge, 7 and 10 mm line
- Cleansing agent Bevi Tab alkaline (2 pieces)
- Operating instructions





# Page

# 3. Operating Instructions

#### 3.1 Designated use

- Bevi Handy is appropriate only for chemo-mechanical service cleaning of beverage lines
- Observe information from the manufacturer of equipment and cleansing agent



#### 3.2 Connection

- Remove the dispenser heads from the barrels and unscrew beer lines
- Connect two beer lines with the connecting piece
- Connect the water supply (2) with the rinsing pipe 3/8" under the counter
- Place the water drain (3) into the sink
- Dismount compensator taps or piston taps, and use corresponding cleaning adapters (in case of ball /tap cocks directly connect the connecting hose with the cock)
- Connect the tap connections (1) with the drain sleeve /cleaning adapter



#### 3.3 Cleaning

- Detach the adapter sight glass from the device by slightly turning it to the left, place the cleaning sponge (observe line diameter), and fasten again
- Open the water cock
- Possible beverage residues and accumulation of grime are flushed out of the system
- Close the water cock after the sponge has passed 2 times
- Detach the adapter sight glass, add to the sponge a Bevi Tab placing it flat (see Fig. below), and fasten again
- Open the water cock
- When using Bevi Tab, close the water cock after cleansing agent and sponge have reached the opposite adapter sight glass
- Let it act for 15 to 30 minutes
- Open the water cock and rinse sufficiently
- Change the travel direction of the sponge several times using the operating lever
- Pay attention that the equipment is free from cleansing agent, check e.g. with pH indicator paper



## 4. Cleaning and Service

• Disinfect inside and outside of the equipment in regular intervals, e. g. with Bevi Desinfect (Attention: do not use alcohol-containing agents)

## 5. General Information

- It is only allowed to connect the equipment with water cocks without low-pressure flow heaters
- Protect the equipment against temperatures below freezing point (risk of freezing and destruction of the pump)
- Do only use customary cleansing agents (e. g. Bevi Tab)
- When operating the equipment properly the warranty for components is of 1 year





# 6. Illustration and Components



No.	Denomination	
1	Line connection	
2	2 Water supply	
3	Adapter sight glass	
4	Operating lever	

# 7. Spare Parts

ltem no.	Component Bevi Handy
88240177	Inside housing element with base (glued) and fitted piston*
88240223	Inside housing element with fitted piston* and sight glass-
88240229	Base (blue) & metal plate
88110102	Adapter Handy bayonet catch, blue
88110101	Adapter Handy SK 16.30 with sight glass
88120116	Adapter sight glass, 10 mm
88240176	Conical handle
88404112	Feed line beer hose, with sleeve & screw joint
88404113	Beer hose drain
88404114	Connecting hose equipment cock with clamp
88240157	Rinsing pipe connection/hose connection 3/8"
88120106	Gaskets 38 x 3 (observe size!)
88403201	Cleaning brush, small
85007562	Cellar connecting piece
88410007	Cleaning sponge, 7 mm line, VE 100
88410010	Cleaning sponge, 10 mm line, VE 100

\* the yellow piston is not available as single piece because it must be individually fitted.

### 8. Technical Information

- Item No.:
- Standard connector:
- Work range:
- Weight:
- Measures:

88.110.000 3/8" Wing screw fitting 1 to 6 bar 1.7 kg 140x240x120 mm (HxWxD)

# CE

BeviClean strives for continuous improvement and reserves the right to up-date or change technical data without prior notice.



Carl-Benz-Straße 5 · D-56218 Mülheim-Kärlich T: +49 2630 / 966 30-0 · F: +49 2630 / 966 30-20 www.beviclean.com · info@beviclean.com