

VIKLUND FINGERPRINT LEVER

1. Programming Admin Fingerprint

Step 1. Press the set key until the blue light flashes to enter the system setting

Step 2. For the first time, press fingerprint 5 times. When the green light is on, it means the entry is successful

Step 3. For the second / third time, the blue light flashes, and the green light is on, indicating that the entry is successful. Verify the administrator, the blue light is always on, indicating that the verification is successful.

Step 4. Press the fingerprint 5 times, the green light is on, indicating that the entry is successful

Pls note: The first three fingerprint users are administrators, the fourth or more fingerprint users are ordinary users

2. Programming User Fingerprint

Step 1. For the fourth to twenty, the blue light flashes, and the green light is on, indicating that the entry is successful.

Step 2. Verify the administrator, the blue light is always on, indicating that the verification is successful.

Step 3. Press the fingerprint 5 times, the green light is on, indicating that the entry is successful

6. Erase Admin Fingerprint

Long press the set key for 9 seconds, the red light will flash. Let go and restore factory settings

7. Erase User Fingerprint

Long press the set key for 9 seconds, the red light will flash. Let go and restore factory settings

THE MAXIMUM NUMBER OF FINGERPRINTS INPUT IS 20