

Aether • quickstart

Midnight / Sand • one-pager

Unbox • Pads, USB-C cable, hard case, quick card. Charge once before first long listen (LED white = ready).

Pair • Hold the mark button 3s until you hear the chime. Choose • Aether Midnight• or • Aether Sand• in Bluetooth settings.

Fit • Rotate the yoke until the pads seal without clamping. Glasses? Loosen one click. ANC: single press on the right cup.

Aether ´• quickstart â continued

Care â Wipe pads monthly. Store in the case, not a bag with keys. Firmware updates arrive in the companion page linked from this profile.

Support â Sample product document for demonstration. Real serial support would live on the manufacturer site linked from the profile actions.