




Wiring Diagram for Eaton PXM Series meter in a GE small case (2 1/2 Elements) with Power Supply Connected, SUSI Adapters # SWDGS6-PXM



Before installing verify
voltage level to Control
Power will not exceed the
meters max range.

Back View

Notes:

1. Connect "GND" as needed during Installations.
2. Fuses are recommended