




Wiring Diagram for Eaton PXM Series meter in a GE Large case (3 Elements) with Power Connected SUSI Adapters # SWDGL9-PXM



Before installing verify
voltage level to Control
Power will not exceed the
meters max range.

Back View

Notes:

1. Connect "GND" as needed during Installations.
2. Fuses are recommended