




Wiring Diagram for Eaton PXM series meter in a Westinghouse case with Power Connected SUSI Adapters # SWDWS9-PXM and SWDWL9-PXM



Before installing verify voltage level to Control Power will not exceed the meters max range.

Back View

Notes:

1. Factory connected A phase voltage to the Control Power to power the meter electronics.
2. Connect GND as needed
3. Fuses Recommended