




Wiring Diagram for Eaton PXM Series meter in a Westinghouse FT-21 case (2 1/2 Element) with Power Supply Connected, SUSI Adapters # SWDWS6-PXM & SWDWL6-PXM



Before installing verify
voltage level to Control
Power will not exceed the
meters max range.

Back View

Notes:

1. Connect "GND" as needed during installation
2. Fuses are recommended