




Wiring Diagram for Accuenergy Acuvim II meter in a SUSI Adapters # SWF3710-AC2



Notes:

1. Connect GND as needed
2. Fuses Recommended

Back View