


PARTS BREAKDOWN



No.	Part #	Description	Qty
25	60010331	Power Cable Clip	1
24	60010330	Meter Cable Clip	1
23	60010124	Power Cable	1
22	60010240	Display-PCB cable	1
21	60010115	Meter Cable	1
20	80080130	785 Face Label	1
19		785 Display Plate(Black)	1
18	60010286	785 Housing(Black)	1
17	60010180	Bnt85HE Display (Before Aug. 15, 2019)	1
	60021979	Bnt85HE Display (After Aug. 15, 2019)	
16	60010673	Screw-ST2.9×10	8
15	60010178	Bnt85HE Main Pcb(UF) (Before Aug. 15, 2019)	1
	60010179	Bnt85HE Main Pcb(UF) (After Aug. 15, 2019)	
	60021982	Bnt85HE Main Pcb(DF) (Before Aug. 15, 2019)	
	60021981	Bnt85HE Main Pcb(DF) (After Aug. 15, 2019)	
14	92393	Bnt85 Motor	1
13	60095658	Motor Pin	1
12	60010574	Screw-ST3.5x13	8
11	60010573	Bnt85HE Mounting Plate	1
10	92389	Bnt85 Drive Gear	1
9	60010575	Screw-4.2×12	1
8	60010661	Washer-4x12	1
5	60095102	Gear, Brine, 85HE(UF)	1
	60095103	Gear, Brine, 85HE(DF)	
4	60010099	Screw-2.9×13	1
3	60010100	Washer-3x13	1
2	92391	Bnt85HE Main Gear	1
1	60095093	Bnt785HE Base(Black)	1