


Important: Read all instructions prior to installation.

**LRS-WS-12-MCT5
LRS-WS-18-MCT5**


LED Wall Sconce Light



Safety and Notes

- Product should be installed and serviced in accordance with applicable national, state, and local building and electrical codes.
- To reduce the risk of electric shock, ensure that the main power source and circuit breakers are switched off before performing any installation or wiring procedures.
- Avoid looking directly into lamp when illuminated.
- Ensure all mounts are securely attached and will support the weight of the fixture. Failure to properly support fixture may result in damage or injury, for which the manufacturer does not assume responsibility.
- There are no serviceable parts inside this fixture. Do not attempt to dismantle or service this fixture in any way. If LEDs or protective lens cover are damaged, the fixture must be replaced.
- Not intended for recess mounting in any type of installation.
- Use minimum 18 AWG coated wire for supply leads and connect to 120 VAC only.

Wiring Diagram



Specifications

Model	WSR/WSS Series
Operating Temperature	-22°–104° F (-30°–40° C)
Environmental Rating	Suitable for wet locations

Check product label for specific electrical specifications related to installation.
Improper installation will void warranty.

Installation

1. Turn of breaker to remove supply power from circuit.
2. Attach the provided mounting plate to junction box.
Note: Ensure the grounding screw is facing outward and the two fixture mounting screw holes align with the desired fixture orientation.
3. Connect wiring, see the 'Wiring Diagram' above.
4. Select the CCT needed.
(with 2700K/3000K/3500K/4000K/5000K for selection).
5. Place the fixture over the mounting plate, aligning the two mounting screw holes on the plate with the two screw holes on the fixture, and secure using the provided hardware.
Note: To ensure a weatherproof seal, use silicone sealant around the base of the light where it meets the mounting surface.
6. Restore supply power.

