



FLASH TEST REPORT

Execution

State of charge **56.14 %**
Date 25/02/2025 08:21:59
Executed by Carla AB

Vehicle

Brand Tesla
Model Model 3 - 78,8 kWh
VIN LRW3E7EK1NC514590
Mileage 73,940 km

Analysis Result

AVILOO SCORE

94

/ 100

High voltage battery usage and history

Analysis of charging & driving behavior

66 / 70

High voltage battery performance

Analysis of cell voltages and module temperatures.

28 / 30

High voltage battery control unit

Check of signals and calculations of the battery management control unit.



Vehicle communication interface

Check of communication via the diagnostic interface.



Dr. Marcus Berger
CEO and Partner

DI Wolfgang Berger MBA
CSO and Founder

DI Nikolaus Mayerhofer
CTO and Founder



EXPLANATION OF THE BATTERY FLASH TEST

ANALYSIS METHOD

The analysis performed is a combined result of: The communication quality between the diagnostic hardware AVILOO Box and the on-board diagnostic interface of the vehicle. The live battery data and data that indicates the previous use of the high voltage battery, which is made available to the AVILOO Box by the battery management system during the measurement. The plausibility check and classification of the battery condition using the collected values and a comparison with the AVILOO Battery Cloud using Big Data algorithms.

FLASH TEST EXECUTION PROTOCOL

- 08:21:55
- AVILOO Box connected.
- ✓
- FLASH Test started.
- ✓
- Vehicle detected.
- ✓
- Starting data acquisition.
- ✓
- Finished data acquisition.
- ✓
- Analyzing data.
- ✓
- Analysis completed.

DETAILED RESULTS OF PERFORMED CHECKS

Vehicle Information

VIN	LRW3E7EK1NC514590
Date	25/02/2025 08:21:59
Mileage	73,940 km

Measurements High Voltage System

Battery temperature	15.5 °C
Maximum cell temperature deviation	1 °C
Pack voltage	371.84 V
Maximum cell voltage deviation	4 mV
Peak current during check	-6.63 A
State of Health (SoH - read from car manufacturer)*	93.91 %

*The SoH shown here was not calculated by AVILOO but corresponds to the SoH read out from the battery management system and calculated by the manufacturer. AVILOO therefore does not guarantee the correctness of this SoH.

