



## GM AND BMW 5L40-E BONDED PISTON INSTALLERS

5L40-E Bonded Pistons are now available from two aftermarket sources. Transtec, Corteco and Precision International. These pistons come only in kits. The Transtec kit consists of 9 pistons that will fit 2002 and up models. Precision International has three different kits. 1. Covers 99-05 models, combo, which consists of 14 pistons. 2. To cover 99-05 BMW AWD vehicles, this kit consists of 9 pistons. 3. To cover 99-05 models except AWD, which consists of 11 pistons. The next issue is getting pistons installed. You may be able to sneak a few of these pistons into their drums without installers, but the center support is not forgiving. The Center Support has no chamfers to allow any ease of assembly. There are two options available to install these pistons. Option 1. Use the sizing cones and SEAL-E-ZEE spray, available from Lube Gard. Size the inner and outer piston seals of the piston with the cones then spray the rubber as directed on the label. This will freeze the rubber so the piston can be installed. See Figure 1. Option 2. Purchase the installers from your local distributor or Kent Moore SPX. **Note: the Kent Moore numbers listed are for 2002 up models only.** Refer to the updated part numbers listed below.


### **Option 1 Part numbers ,See Figure 1**

SEAL-E-ZEE Original.....	#19500
SEAL-E-ZEE Xtreme.....	#19501
SEAL-E-ZEE Application cones.....	#19600

### **Option 2 Kent Moore Part numbers**

DIRECT CLUTCH PISTON INNER (Figure 2).....	J-45133
FORWARD CLUTCH PISTON INNER (Figure 3).....	J-45134
COAST CLUTCH PISTON INNER (Figure 4).....	J-45132
OVERDRIVE CLUTCH PISTON OUTER (Figure 5).....	J-45135
LOW REVERSE CLUTCH PISTON INNER (Figure 6).....	J-45140
LOW REVERSE CLUTCH PISTON OUTER (Figure 6).....	J-45136
LOW REVERSE CLUTCH PISTON PUSHER (Figure 6).....	J-45688
2ND CLUTCH PISTON INNER AND OUTER <i>KIT</i> (Figure 7).....	J-46240
2ND COAST PISTON INNER AND OUTER WITH PUSHER <i>KIT</i> (Figure 8).....	J-46239

## ALTERNATIVE BONDED PISTON INSTALLERS



*Note: To use these installers find two cones to compress the inner and outer lip of the bonded piston. Spray SEAL-E-ZEE as directed in the instructions on the label, lubricate drum surface and install piston.*


Copyright © 2008 ATSG

Figure 1

## DIRECT CLUTCH PISTON INSTALLATION

INSTALLER AVAILABLE

J-45133




Copyright © 2008 ATSG

Figure 2

## FORWARD CLUTCH PISTON INSTALLATION

INSTALLER AVAILABLE  
J-45134




Copyright © 2008 ATSG

Figure 3

## COAST CLUTCH PISTON INSTALLATION

INSTALLER AVAILABLE  
J-45132




Copyright © 2008 ATSG

Figure 4

## OVERDRIVE CLUTCH PISTON INSTALLATION

INSTALLER AVAILABLE  
J-45135




Copyright © 2008 ATSG

Figure 5

## LOW REVERSE PISTON INSTALLATION


INSTALLERS AVAILABLE  
J-45140 LOW REVERSE INNER  
J-45136 LOW REVERSE OUTER  
J-45688 LOW REVERSE PISTON PUSHER



Copyright © 2008 ATSG

Figure 6

## 2ND PISTON INSTALLATION INSTALLERS ONLY AVAILABLE IN KIT J-46240




Copyright © 2008 ATSG

Figure 7



## 2ND COAST PISTON INSTALLATION INSTALLERS ONLY AVAILABLE IN KIT J-46239



Copyright © 2008 ATSG

Figure 8